

Service Manual

ORDER NO.
ARP2514

COMPACT DISC PLAYER

PD - 65 KU

PD - S901 HEM, HB, SD

- Refer to the service manual ARP2297 for PD - 41.
- This manual is applicable to the following : PD - 65/KU ; PD - S901/HEM, HB and SD.

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan

PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A.

PIONEER ELECTRONICS OF CANADA, INC. 300 Allstate Parkway Markham, Ontario L3R 0P2 Canada

PIONEER ELECTRONIC [EUROPE] N.V. Haven 1087 Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911

© **PIONEER ELECTRONIC CORPORATION 1992**

FN MAY 1992 Printed in Japan


1. CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

PD-65/KU, PD-S901/HEM, HB, SD and PD-41/KU have the same construction except for the following :

| Mark | Symbol & Description | Part No. | | | | | Remarks |
|----------|---------------------------|--------------|--------------|-----------------|----------------|----------------|---|
| | | PD-41 /KU | PD-65 /KU | PD-S901 /HEM | PD-S901 /HB | PD-S901 /SD | |
| NSP | MOTHER BOARD assembly | PMW1486 | | | | | |
| ● | MOTHER BOARD assembly | | PWM1647 | PWM1648 | PWM1649 | PWM1650 | |
| ● | MAIN BOARD assembly | PWZ2150 | | | | | |
| NSP | MAIN BOARD assembly | | PWZ2382 | PWZ2383 | PWZ2384 | PWZ2385 | |
| NSP | PRIMARY BOARD assembly | PWZ2158 | PWZ2158 | PWZ2159 | PWZ2161 | PWZ2160 | |
| ● | ANALOG BOARD assembly | PWM1490 | PWM1643 | PWM1643 | PWM1644 | PWM1643 | |
| ● | SUB BOARD assembly | PWM1493 | PWM1493 | PWM1494 | PWM1494 | PWM1494 | |
| NSP | FUNCTION A BOARD assembly | PWZ2168 | PWZ2168 | PWZ2169 | PWZ2169 | PWZ2169 | |
| NSP | FUNCTION B BOARD assembly | PWZ2170 | PWZ2170 | PWZ2171 | PWZ2171 | PWZ2171 | |
| | FL sheet | PAM1514 | PAM1290 | PAM1251 | PAM1251 | PAM1514 | |
| NSP | Badge | PAN1035 | AAM1001 | PAN1035 | PAN1035 | PAN1035 | |
| NSP | Front panel | PAN1211 | PAN1254 | PAN1255 | PAN1255 | PAN1255 | |
| | Front panel assembly | PEA1167 | PEA1239 | PEA1240 | PEA1240 | PEA1240 | |
| | Side sash | | PAN1220 | | | | For control panel |
| | Side rubber | PEB1180 | | PEB1180 | PEB1180 | PEB1180 | |
| | Wood collar | | PNW1238 | | | | For side board |
| NSP | Wood spacer | | PEC1001 | | | | For side board |
| Δ | AC power cord | PDG1015 | PDG1015 | PDG1003 | PDG1036 | PDG1013 | |
| Δ | Power transformer (8VA) | PTT1166 | PTT1166 | PTT1167 | PTT1167 | PTT1168 | |
| Δ | Power transformer (15VA) | PTT1206 | PTT1206 | PTT1207 | PTT1207 | PTT1208 | |
| Δ | Strain relief | CM-22C | CM-22C | CM-22B | CM-22B | CM-22B | |
| Δ | Voltage selector | | | | | PSB1002 | |
| | 33P F.F.C / 30V | PDD1094 | PDD1094 | | | | |
| | 31P F.F.C / 30V | | | PDD1092 | PDD1092 | PDD1092 | |
| | Protector F | PHA1145 | PHA1171 | PHA1145 | PHA1145 | PHA1145 | For packing |
| | Protector R | PHA1146 | PHA1172 | PHA1146 | PHA1146 | PHA1146 | For packing |
| | Packing case | PHG1677 | PHG1813 | PHG1812 | PHG1812 | PHG1812 | |
| | Screw | | PBA1038 | | | | For side board |
| | Side board L | | PMM1039 | | | | |
| | Side board R | | PMM1040 | | | | |
| NSP | Rear base | PNA1538 | PNA1861 | PNA1858 | PNA1859 | PNA1860 | |
| NSP | Under base | PNA1683 | PNA1884 | PNA1683 | PNA1683 | PNA1683 | |
| NSP | Shield plate | PNB1299 | PNB1407 | PNB1299 | PNB1299 | PNB1299 | |
| NSP | L angle | PNB1316 | PNB1406 | PNB1316 | PNB1316 | PNB1316 | |
| | Control panel | PNW2066 | PNW2065 | PNW2066 | PNW2066 | PNW2066 | |
| | Mini plug cord | PDE-319 | PDE-319 | | | | |
| | Remote control unit | PWW1058 | PWW1057 | PWW1058 | PWW1058 | PWW1058 | |
| | Operating instructions | PRE1149 | PRE1165 | PRE1165 | PRE1165 | PRE1165 | English, French |
| | Operating instructions | | | PRF1058 | | | German, Italian, Dutch, Swedish, Spanish, Portuguese |



LIST of assemblies (PD-41, PD-65, PD-S901)

- MOTHER BOARD assembly
 - MAIN BOARD assembly
 - PRIMARY BOARD assembly
- SUB BOARD assembly
 - FUNCTION A BOARD assembly
 - FUNCTION B BOARD assembly

•Exploded views for PD-65/KU only.

2. PCB PARTS LIST

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω \rightarrow 56 \times 10¹ \rightarrow 561 RD1/8PM $\overline{561}$ J
47k Ω \rightarrow 47 \times 10³ \rightarrow 473 RD1/4PS $\overline{473}$ J
0.5 Ω \rightarrow 0R5 RN2H $\overline{0R5}$ K
1 Ω \rightarrow 010 RSIP $\overline{010}$ K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k Ω \rightarrow 562 \times 10¹ \rightarrow 5621 RN1/4PC $\overline{5621}$ F

FOR PD - 65/KU, PD - S901/HEM,HB AND SD types.


- For part numbers of PCB assemblies, refer to page 2.

| Mark | No. | Description | Parts No. | Mark | No. | Description | Parts No. |
|-------------------------------------|-----------------|-------------|-----------|------------|----------------------|-------------|-----------|
| MAIN BOARD ASSEMBLY | | | | L391,392 | AXIAL COIL | LAUR22K | |
| SEMICONDUCTORS | | | | L393 | AXIAL INDUCTOR | LAU010K | |
| IC11 REGULATOR IC NJM7805FA | | | | CAPACITORS | | | |
| IC12 REGULATOR IC NJM7905FA | | | | C10,11 | CERAMIC CAPACITOR | PCL1029 | |
| IC13 REGULATOR IC NJM7808FA | | | | C13-20 | CERAMIC CAPACITOR | PCL1029 | |
| IC14 REGULATOR IC NJM7908FA | | | | C21,22 | ELECT. CAPACITOR | CEAS222M25 | |
| IC30-32 IC PROTECTOR ICP-N10 | | | | C23 | ELECT. CAPACITOR | CEAS102M25 | |
| IC60 SYSTEM RESET IC M51957AL | | | | C25,26 | ELECT. CAPACITOR | CEAS222M16 | |
| IC101 PRE AMP IC CXA1471S | | | | C27,28 | ELECT. CAPACITOR | CEAS222M25 | |
| IC151 SERVO IC CXA1372S | | | | C29,30 | ELECT. CAPACITOR | CEAS102M16 | |
| IC201 POWER OP-AMP IC LA6520 | | | | C51 | ELECT. CAPACITOR | CEAS101M50 | |
| IC202 POWER OP-AMP IC LA6517 | | | | C52 | ELECT. CAPACITOR | CEAS221M50 | |
| IC301 EFM DEMODULATION IC CXD2500AQ | | | | C53 | ELECT. CAPACITOR | CEAS100M50 | |
| IC331 IC MC74HCU04N | | | | C54 | ELECT. CAPACITOR | CEAS470M50 | |
| Q51 TRANSISTOR 2SB1187 | | | | C55 | ELECT. CAPACITOR | CEAS330M35 | |
| Q101 TRANSISTOR 2SA854S | | | | C56 | ELECT. CAPACITOR | CEAS101M50 | |
| Q240 TRANSISTOR 2SA933S | | | | C61 | ELECT. CAPACITOR | CEASR33M50 | |
| Q241 TRANSISTOR 2SC1740S | | | | C62 | ELECT. CAPACITOR | CEAS010M50 | |
| Q301 TRANSISTOR DTC124ES | | | | C101,102 | ELECT. CAPACITOR | CEAS101M50 | |
| Q302 TRANSISTOR DTA124ES | | | | C103 | CERAMIC CAPACITOR | CCDCH200J50 | |
| Q321,331 TRANSISTOR DTC124ES | | | | C104 | ELECT. CAPACITOR | CEAS101M10 | |
| Q351 TRANSISTOR DTA124ES | | | | C105,106 | ELECT. CAPACITOR | CEAS101M50 | |
| Q391 TRANSISTOR DTC124ES | | | | C107,108 | CERAMIC CAPACITOR | CGCYX103K25 | |
| D11-14 DIODE 11ES2 | | | | C110 | CERAMIC CAPACITOR | CKCYF103Z50 | |
| D25 DIODE RB-152LF | | | | C151-154 | ELECT. CAPACITOR | CEAS101M50 | |
| D51,52 DIODE 11ES2 | | | | C155 | CERAMIC CAPACITOR | CKCYB182K50 | |
| D53 ZENER DIODE MTZ27C | | | | C156 | CERAMIC CAPACITOR | CGCYX333K25 | |
| D54 ZENER DIODE MTZJ20A | | | | C157 | CERAMIC CAPACITOR | CGCYX103K25 | |
| D56 DIODE 11ES2 | | | | C158,159 | MYLAR FILM CAPACITOR | CQMA104K50 | |
| D321 DIODE 1SS254 | | | | C160 | ELECT. CAPACITOR | CEAS4R7M50 | |
| D391-394 DIODE(PD-65 only) 1SS254 | | | | C161 | MYLAR FILM CAPACITOR | CQMA104K50 | |
| D395-399 DIODE 1SS254 | | | | C162 | ELECT. CAPACITOR | CEAS010M50 | |
| COILS, FILTERS | | | | C163 | MYLAR FILM CAPACITOR | CQMA104K50 | |
| L30 | AXIAL INDUCTOR | LAU010K | | C164 | CERAMIC CAPACITOR | CGCYX103K25 | |
| L301 | RADIAL INDUCTOR | LFA010K | | C166 | CERAMIC CAPACITOR | OCCSL101J50 | |
| L332 | COIL | PTL1003 | | C167 | CERAMIC CAPACITOR | CKCYF103Z50 | |
| | | | | C168 | CERAMIC CAPACITOR | CGCYX333K25 | |

| Mark | No. | Description | Parts No. |
|-----------|-----------|--------------------------|--------------|
| | C169 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C170 | CERAMIC CAPACITOR | CKCYB333K50 |
| | C171,172 | CERAMIC CAPACITOR | CKCYB473K50 |
| | C202 | CERAMIC CAPACITOR | CKCYF103Z50 |
| | C212 | CERAMIC CAPACITOR | CKCYB273K50 |
| | C216-219 | ELECT. CAPACITOR | CEAS221M50 |
| | C232 | CERAMIC CAPACITOR | CKCYF103Z50 |
| | C301 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C302 | ELECT. CAPACITOR | CEAS471M50 |
| | C303 | ELECT. CAPACITOR | CEAS101M50 |
| | C304 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C305 | ELECT. CAPACITOR | CEAS221M50 |
| | C306 | CERAMIC CAPACITOR | CKCYB152K50 |
| | C307 | CERAMIC CAPACITOR | CGCYX473K50 |
| | C308 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C309 | ELECT. CAPACITOR | CEASR473K50 |
| | C310 | CERAMIC CAPACITOR | CKCYF103Z50 |
| | C311 | CERAMIC CAPACITOR | CKCYB102K50 |
| | C313 | CERAMIC CAPACITOR | CKCYF103Z50 |
| | C314 | CERAMIC CAPACITOR | CGDYX103K25 |
| | C331 | CERAMIC CAPACITOR | CGCYX473K50 |
| | C332 | ELECT. CAPACITOR | CEAS101M50 |
| | C334 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C335 | ELECT. CAPACITOR | CEAS470M50 |
| | C336 | AUDIO FILM CAPACITOR | CFTXA103K25 |
| | C337 | CERAMIC CAPACITOR | OCCSL471K50 |
| | C339,340 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C391 | CERAMIC CAP.(PD-65 only) | CGCYX103K25 |
| | C392 | CERAMIC CAP.(PD-65 only) | OCCSL101J50 |
| | C395 | CERAMIC CAPACITOR | CCDSL100J50 |
| RESISTORS | | | |
| | VR102 | VR(22k) | VRTB6VS2 |
| | VR103 | VR(1K) | VRTB6VS1 |
| | VR151,152 | VR(22k) | VRTB6VS2 |
| | | Other resistors | RD1/6PM |
| OTHERS | | | |
| | CN101 | CONNECTOR | 52045-1610 |
| | CN351 | CONNECTOR(PD-65) | HLEM33S-1610 |
| | CN351 | CONNECTOR(PD-S901) | HLEM31S-1610 |
| | JA331 | OPTICAL OUTPUT JACK | TOTX178 |
| | JA332 | JACK | PKB1004 |
| | JA391,392 | JACK(PD-65 only) | RKN1004 |
| | JA393 | JACK | RKN1004 |

PRIMARY BOARD ASSEMBLY

| | | | |
|-----------|----|--------------------------|---------|
| SWITCH | | | |
| Δ | S1 | SWITCH | PSA-009 |
| CAPACITOR | | | |
| Δ | C1 | CAPACITOR (0.01 μ F) | VCG-048 |
| OTHER | | | |
| Δ | | TERMINAL(PD-65) | RKC-061 |



●Exploded views for PD-65/KU only.

| Mark No. | Description | Parts No. |
|------------------|--------------------------|-------------|
| C169 | CERAMIC CAPACITOR | CGCYX103K25 |
| C170 | CERAMIC CAPACITOR | CKCYB332K50 |
| C171,172 | CERAMIC CAPACITOR | CKCYB472K50 |
| C202 | CERAMIC CAPACITOR | CKCYF103Z50 |
| C212 | CERAMIC CAPACITOR | CKCYB272K50 |
| C216-219 | ELECT. CAPACITOR | CEAS221M25 |
| C232 | CERAMIC CAPACITOR | CKCYF103Z50 |
| C301 | CERAMIC CAPACITOR | CGCYX103K25 |
| C302 | ELECT. CAPACITOR | CEAS471M10 |
| C303 | ELECT. CAPACITOR | CEAS101M50 |
| C304 | CERAMIC CAPACITOR | CGCYX103K25 |
| C305 | ELECT. CAPACITOR | CEAS221M25 |
| C306 | CERAMIC CAPACITOR | CKCYB152K50 |
| C307 | CERAMIC CAPACITOR | CGCYX473K25 |
| C308 | CERAMIC CAPACITOR | CGCYX103K25 |
| C309 | ELECT. CAPACITOR | CEASR47M50 |
| C310 | CERAMIC CAPACITOR | CKCYF103Z50 |
| C311 | CERAMIC CAPACITOR | CKCYB102K50 |
| C313 | CERAMIC CAPACITOR | CKCYF103Z50 |
| C314 | CERAMIC CAPACITOR | CGDYX104M25 |
| C331 | CERAMIC CAPACITOR | CGCYX473K25 |
| C332 | ELECT. CAPACITOR | CEAS101M25 |
| C334 | CERAMIC CAPACITOR | CGCYX103K25 |
| C335 | ELECT. CAPACITOR | CEAS470M25 |
| C336 | AUDIO FILM CAPACITOR | CFTXA103J50 |
| C337 | CERAMIC CAPACITOR | CCCSL471J50 |
| C339,340 | CERAMIC CAPACITOR | CGCYX103K25 |
| C391 | CERAMIC CAP.(PD-65 only) | CGCYX103K25 |
| C392 | CERAMIC CAP.(PD-65 only) | CCCSL101J50 |
| C395 | CERAMIC CAPACITOR | CCDSL100D50 |
| RESISTORS | | |
| VR102 | VR(22k) | VRTB6VS223 |
| VR103 | VR(1K) | VRTB6VS102 |
| VR151,152 | VR(22k) | VRTB6VS223 |
| | Other resistors | RD1/6PM□□□J |
| OTHERS | | |
| CN101 | CONNECTOR | 52045-1610 |
| CN351 | CONNECTOR(PD-65) | HLEM33S-1 |
| CN351 | CONNECTOR(PD-S901) | HLEM31S-1 |
| JA331 | OPTICAL OUTPUT JACK | TOTX178 |
| JA332 | JACK | PKB1004 |
| JA391,392 | JACK(PD-65 only) | RKN1004 |
| JA393 | JACK | RKN1004 |

PRIMARY BOARD ASSEMBLY


| | | |
|------------------|--------------------|---------|
| SWITCH | | |
| △ S1 | SWITCH | PSA-009 |
| CAPACITOR | | |
| △ C1 | CAPACITOR (0.01μF) | VCG-048 |
| OTHER | | |
| △ | TERMINAL(PD-65) | RKC-061 |

| Mark No. | Description | Parts No. |
|------------------------------|----------------------|-------------|
| ANALOG BOARD ASSEMBLY | | |
| SEMICONDUCTORS | | |
| △ IC501,502 | REGULATOR IC | NJM7805FA |
| IC512 | LOGIC IC | TC74HCU04AP |
| IC513 | IC | PD0116A |
| IC522,523 | D/A CONVERTER IC | PD2028B |
| IC554,555 | OP-AMP IC | NJM5532DD |
| △ IC601 | REGULATOR IC | NJM7815FA |
| △ IC602 | REGULATOR IC | NJM7915FA |
| △ IC620,621 | IC PROTECTOR | ICP-N15 |
| Q521 | TRANSISTOR | DTC124ES |
| Q522,523 | TRANSISTOR | DTA124ES |
| Q524,525 | TRANSISTOR | DTC124ES |
| Q554-557 | TRANSISTOR | 2SC3068 |
| Q558 | N-FET | 2SK246 |
| Q559,560 | P-FET | 2SJ103 |
| Q561 | N-FET | 2SK246 |
| Q562,563 | TRANSISTOR | 2SC3068 |
| D521 | DIODE | 1SS254 |
| D550,551 | DIODE | 1SS254 |
| D570,571 | DIODE | 1SS254 |
| △ D610-613 | DIODE | 10DF2 |
| △ D620-627 | DIODE | 10DF2 |
| COILS, FILTERS | | |
| L511,512 | AXIAL INDUCTOR | LAU010K |
| L513,514 | AMORPHOUS BEAD | PTH1006 |
| L518,519 | FILTER | PTH1011 |
| L522,523 | AXIAL INDUCTOR | LAU010K |
| L525,526 | AXIAL INDUCTOR | LAU010K |
| L551-554 | FERRITE BEADS | VTH1013 |
| F520,521 | FILTER | VTH1001 |
| CAPACITORS | | |
| C501,502 | AUDIO FILM CAPACITOR | CFTXA104J50 |
| C503,504 | CERAMIC CAPACITOR | PCL1029 |
| C505 | ELECT. CAPACITOR | CEAS101M25 |
| C506,507 | AUDIO FILM CAPACITOR | CFTXA104J50 |
| C510 | AUDIO FILM CAPACITOR | CFTXA473J50 |
| C511 | CERAMIC CAPACITOR | PCL1029 |
| C512 | AUDIO FILM CAPACITOR | CFTXA103J50 |
| C514 | CERAMIC CAPACITOR | CGCYF473Z25 |
| C515 | AUDIO FILM CAPACITOR | CFTXA103J50 |
| C516 | ELECT. CAPACITOR | CEAS102M16 |
| C517,518 | CERAMIC CAPACITOR | CCCCH120J50 |
| C519 | ELECT. CAPACITOR | CEAS102M16 |
| C520 | ELECT. CAPACITOR | CEAS470M50 |
| C521 | MYLAR FILM CAPACITOR | CQMA473J50 |
| C522 | AUDIO FILM CAPACITOR | CFTXA682J50 |
| C523 | CERAMIC CAPACITOR | PCL1029 |
| C524 | ELECT. CAPACITOR | CEAS102M16 |
| C526 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C527 | MYLAR FILM CAPACITOR | CQMA473J50 |
| C528 | ELECT. CAPACITOR | CEAS102M16 |
| C529 | MYLAR FILM CAPACITOR | CQMA473J50 |
| C530,531 | AUDIO FILM CAPACITOR | CFTXA682J50 |
| C532 | ELECT. CAPACITOR | CEAS102M16 |
| C534 | AUDIO FILM CAPACITOR | CFTXA104J50 |

| Mark No. | Description | Parts No. |
|------------------|----------------------|--------------|
| C535 | ELECT. CAPACITOR | CEAS102M16 |
| C538,539 | CERAMIC CAPACITOR | CCCCH120J50 |
| C540,541 | CERAMIC CAPACITOR | CCDCH221J50 |
| C542,543 | CERAMIC CAPACITOR | CCCCH181J50 |
| C544,545 | CERAMIC CAPACITOR | CCCCH330J50 |
| C546,547 | CERAMIC CAPACITOR | CGCYF473Z25 |
| C548 | CERAMIC CAPACITOR | CCCCH080D50 |
| C549 | CERAMIC CAPACITOR | CCCCH080D50 |
| C550,551 | CERAMIC CAPACITOR | CCCCH181J50 |
| C552,553 | CERAMIC CAPACITOR | CCCCH330J50 |
| C554,555 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C556,557 | ELECT. CAPACITOR | CEAS102M16 |
| C558,559 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C560-563 | CERAMIC CAPACITOR | CCCCH470J50 |
| C564,565 | MYLAR FILM CAPACITOR | CQMA681J50 |
| C566,567 | MYLAR FILM CAPACITOR | CQMA562J50 |
| C568-571 | ELECT. CAPACITOR | CEAS471M50 |
| C572,573 | (47/50) | PCH1072 |
| C576,577 | ELECT. CAPACITOR | CEAS102M16 |
| C578,579 | CERAMIC CAPACITOR | PCL1029 |
| C581 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C582,583 | AUDIO FILM CAPACITOR | CFTXA683J50 |
| C586 | AUDIO FILM CAPACITOR | CFTXA473J50 |
| C587,588 | ELECT. CAPACITOR | CEANP220M25 |
| C589 | ELECT. CAPACITOR | CEAS102M16 |
| C590 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C591 | AUDIO FILM CAPACITOR | CFTXA682J50 |
| C593,594 | ELECT. CAPACITOR | CEAS102M16 |
| C595 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C597 | ELECT. CAPACITOR | CEAS102M16 |
| C601 | ELECT. CAPACITOR | CENA102M35 |
| C604,605 | ELECTR. CAPACITOR | PCH1102 |
| C606,607 | ELECT. CAPACITOR | CENA102M35 |
| C608-618 | CERAMIC CAPACITOR | PCL1029 |
| RESISTORS | | |
| R502 | CARBON FILM RESISTOR | RD1/4PM331J |
| R514 | CARBON FILM RESISTOR | RD1/4PM331J |
| R540-567 | CARBON FILM RESISTOR | RD1/4PM□□□J |
| R568-581 | CARBON FILM RESISTOR | RDR1/4PM□□□J |
| R582-585 | CARBON FILM RESISTOR | RDR1/2PM□□□J |
| R588,589 | CARBON FILM RESISTOR | RDR1/2PM271J |
| R590,591 | CARBON FILM RESISTOR | RDR1/4PM511J |
| R593,594 | CARBON FILM RESISTOR | RDR1/4PM331J |
| | Other resistors | RD1/6PM□□□J |
| OTHERS | | |
| JA551 | 1P PIN JACK(W) | RKB1010 |
| JA552 | 1P PIN JACK (R) | RKB1011 |
| X512 | XTAL RES (OSC) | PSS1011 |
| CN501 | CONNECTOR(10P) | KPC10 |

FUNCTION A BOARD ASSEMBLY

| | | |
|-----------------------|------------------|---------|
| SEMICONDUCTORS | | |
| IC401 | MICROCOMPUTER,IC | PD4329A |





| | Mark No. | Description | Parts No. |
|--|------------------------------|----------------------|-------------|
| | ANALOG BOARD ASSEMBLY | | |
| | SEMICONDUCTORS | | |
| | △ IC501,502 | REGULATOR IC | NJM7805FA |
| | IC512 | LOGIC IC | TC74HCU04AP |
| | IC513 | IC | PD0116A |
| | IC522,523 | D/A CONVERTER IC | PD2028B |
| | IC554,555 | OP-AMP IC | NJM5532DD |
| | △ IC601 | REGULATOR IC | NJM7815FA |
| | △ IC602 | REGULATOR IC | NJM7915FA |
| | △ IC620,621 | IC PROTECTOR | ICP-N15 |
| | Q521 | TRANSISTOR | DTC124ES |
| | Q522,523 | TRANSISTOR | DTA124ES |
| | Q524,525 | TRANSISTOR | DTC124ES |
| | Q554-557 | TRANSISTOR | 2SC3068 |
| | Q558 | N-FET | 2SK246 |
| | Q559,560 | P-FET | 2SJ103 |
| | Q561 | N-FET | 2SK246 |
| | Q562,563 | TRANSISTOR | 2SC3068 |
| | D521 | DIODE | 1SS254 |
| | D550,551 | DIODE | 1SS254 |
| | D570,571 | DIODE | 1SS254 |
| | △ D610-613 | DIODE | 10DF2 |
| | △ D620-627 | DIODE | 10DF2 |
| | COILS, FILTERS | | |
| | L511,512 | AXIAL INDUCTOR | LAU010K |
| | L513,514 | AMORPHOUS BEAD | PTH1006 |
| | L518,519 | FILTER | PTH1011 |
| | L522,523 | AXIAL INDUCTOR | LAU010K |
| | L525,526 | AXIAL INDUCTOR | LAU010K |
| | L551-554 | FERRITE BEADS | VTH1013 |
| | F520,521 | FILTER | VTH1001 |
| | CAPACITORS | | |
| | C501,502 | AUDIO FILM CAPACITOR | CFTXA104J50 |
| | C503,504 | CERAMIC CAPACITOR | PCL1029 |
| | C505 | ELECT. CAPACITOR | CEAS101M25 |
| | C506,507 | AUDIO FILM CAPACITOR | CFTXA104J50 |
| | C510 | AUDIO FILM CAPACITOR | CFTXA473J50 |
| | C511 | CERAMIC CAPACITOR | PCL1029 |
| | C512 | AUDIO FILM CAPACITOR | CFTXA103J50 |
| | C514 | CERAMIC CAPACITOR | CGCYF473Z25 |
| | C515 | AUDIO FILM CAPACITOR | CFTXA103J50 |
| | C516 | ELECT. CAPACITOR | CEAS102M16 |
| | C517,518 | CERAMIC CAPACITOR | CCCCH120J50 |
| | C519 | ELECT. CAPACITOR | CEAS102M16 |
| | C520 | ELECT. CAPACITOR | CEAS470M50 |
| | C521 | MYLAR FILM CAPACITOR | CQMA473J50 |
| | C522 | AUDIO FILM CAPACITOR | CFTXA682J50 |
| | C523 | CERAMIC CAPACITOR | PCL1029 |
| | C524 | ELECT. CAPACITOR | CEAS102M16 |
| | C526 | MYLAR FILM CAPACITOR | CQMA104J50 |
| | C527 | MYLAR FILM CAPACITOR | CQMA473J50 |
| | C528 | ELECT. CAPACITOR | CEAS102M16 |
| | C529 | MYLAR FILM CAPACITOR | CQMA473J50 |
| | C530,531 | AUDIO FILM CAPACITOR | CFTXA682J50 |
| | C532 | ELECT. CAPACITOR | CEAS102M16 |
| | C534 | AUDIO FILM CAPACITOR | CFTXA104J50 |


| Mark No. | Description | Parts No. |
|----------------------------------|----------------------|--------------|
| C535 | ELECT. CAPACITOR | CEAS102M16 |
| C538,539 | CERAMIC CAPACITOR | CCCCH120J50 |
| C540,541 | CERAMIC CAPACITOR | CCDCH221J50 |
| C542,543 | CERAMIC CAPACITOR | CCCCH181J50 |
| C544,545 | CERAMIC CAPACITOR | CCCCH330J50 |
| C546,547 | CERAMIC CAPACITOR | CGCYF473Z25 |
| C548 | CERAMIC CAPACITOR | CCCCH080D50 |
| C549 | CERAMIC CAPACITOR | CCCCH080D50 |
| C550,551 | CERAMIC CAPACITOR | CCCCH181J50 |
| C552,553 | CERAMIC CAPACITOR | CCCCH330J50 |
| C554,555 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C556,557 | ELECT. CAPACITOR | CEAS102M16 |
| C558,559 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C560-563 | CERAMIC CAPACITOR | CCCCH470J50 |
| C564,565 | MYLAR FILM CAPACITOR | CQMA681J50 |
| C566,567 | MYLAR FILM CAPACITOR | CQMA562J50 |
| C568-571 | ELECT. CAPACITOR | CEAS471M50 |
| C572,573 | (47/50) | PCH1072 |
| C576,577 | ELECT. CAPACITOR | CEAS102M16 |
| C578,579 | CERAMIC CAPACITOR | PCL1029 |
| C581 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C582,583 | AUDIO FILM CAPACITOR | CFTXA683J50 |
| C586 | AUDIO FILM CAPACITOR | CFTXA473J50 |
| C587,588 | ELECT. CAPACITOR | CEANP220M25 |
| C589 | ELECT. CAPACITOR | CEAS102M16 |
| C590 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C591 | AUDIO FILM CAPACITOR | CFTXA682J50 |
| C593,594 | ELECT. CAPACITOR | CEAS102M16 |
| C595 | MYLAR FILM CAPACITOR | CQMA104J50 |
| C597 | ELECT. CAPACITOR | CEAS102M16 |
| C601 | ELECT. CAPACITOR | CENA102M35 |
| C604,605 | ELECTR. CAPACITOR | PCH1102 |
| C606,607 | ELECT. CAPACITOR | CENA102M35 |
| C608-618 | CERAMIC CAPACITOR | PCL1029 |
| RESISTORS | | |
| R502 | CARBON FILM RESISTOR | RD1/4PM331J |
| R514 | CARBON FILM RESISTOR | RD1/4PM331J |
| R540-567 | CARBON FILM RESISTOR | RD1/4PM□□□J |
| R568-581 | CARBON FILM RESISTOR | RDR1/4PM□□□J |
| R582-585 | CARBON FILM RESISTOR | RDR1/2PM□□□J |
| R588,589 | CARBON FILM RESISTOR | RDR1/2PM271J |
| R590,591 | CARBON FILM RESISTOR | RDR1/4PM511J |
| R593,594 | CARBON FILM RESISTOR | RDR1/4PM331J |
| | Other resistors | RD1/6PM□□□J |
| OTHERS | | |
| JA551 | 1P PIN JACK(W) | RKB1010 |
| JA552 | 1P PIN JACK (R) | RKB1011 |
| X512 | XTAL RES (OSC) | PSS1011 |
| CN501 | CONNECTOR(10P) | KPC10 |
| FUNCTION A BOARD ASSEMBLY | | |
| SEMICONDUCTORS | | |
| IC401 | MICROCOMPUTER,IC | PD4329A |

| Mark No. | Description | Parts No. |
|----------------------------------|--------------------|--------------|
| Q402,403 | TRANSISTOR | DTC124ES |
| Q404,405 | TRANSISTOR | DTA124ES |
| D401 | LED | AA0045 |
| D402 | LED | BR0045 |
| D411-416 | DIODE | 1SS254 |
| SWITCHES | | |
| S401-406 | SWITCH | PSG-065 |
| COILS, FILTERS | | |
| L401,402 | AXIAL INDUCTOR | LAU010K |
| CAPACITORS | | |
| C401,402 | ELECT. CAPACITOR | CEJA470M16 |
| C403 | CERAMIC CAPACITOR | CKPUYF103Z25 |
| C404 | ELECT. CAPACITOR | CEJA470M16 |
| C405 | CERAMIC CAPACITOR | CKPUYF103Z25 |
| C406-408 | CERAMIC CAPACITOR | CGCYX103K25 |
| C409 | CERAMIC CAPACITOR | CKCYF103Z50 |
| C411-416 | AXIAL CERAMIC C. | CCPUCH100J50 |
| RESISTORS | | |
| | All resistors | RD1/6PM□□□J |
| OTHERS | | |
| CN401 | CONNECTOR(PD-65) | HLEM33R-1 |
| CN401 | CONNECTOR(PD-S901) | HLEM31R-1 |
| V401 | FL TUBE | PEL1025 |
| X401 | CERAMIC RESONATOR | VSS1014 |
| | REMOTE SENSOR | SBX1610-51 |
| FUNCTION B BOARD ASSEMBLY | | |
| SEMICONDUCTORS | | |
| D403 | LED | SLH-34YC3H3 |
| D404,405 | LED | SLH-34VC3H3 |
| D417 | DIODE | 1SS254 |
| SWITCHES | | |
| S407,408 | SWITCH | PSG-065 |
| CAPACITOR | | |
| C417 | AXIAL CERAMIC C. | CCPUCH100J50 |

3. SCHEMATIC AND PCB CONNECTIONS DIAGRAMS









FUNCTION A BOARD ASSEMBLY

| | |
|-----------|---------|
| X2 | CN401 |
| KU | 33 pins |
| HEM,SD,HB | 31 pins |

KU TYPE ONLY



FUNCTION B BOARD ASSEMBLY



| P.C.B. pattern diagram indication | Corresponding part symbol | Part name | P.C.B. pattern diagram indication | Corresponding part symbol | Part name |
|-----------------------------------|---------------------------|-------------|-----------------------------------|---------------------------|--|
| | | Transistor | | | Ceramic capacitor |
| | | FET | | | Mylar capacitor |
| | | Diode | | | Styrol capacitor |
| | | Zener diode | | | Electrolytic capacitor (Non polarized) |
| | | LED | | | Electrolytic capacitor (Noiseless) |
| | | Varactor | | | Electrolytic capacitor (Polarized) |
| | | Tact switch | | | Power capacitor |
| | | Inductor | | | Semi-fixed resistor |
| | | Coil | | | Resistor array |
| | | Transformer | | | Resistor |
| | | Filter | | | Resonator |
| | | | | | Thermistor |

Line Voltage Selection

Line voltage can be changed with the following steps.

1. Disconnect the AC power cord.
2. Remove the top cover.
3. Change the position of the jumper wires A and B as follows.


| Voltage | Jumper wires A and B position |
|-------------|-------------------------------|
| 220 V-230 V | a |
| 230 V-240 V | b |

4. Stick the line voltage label on the rear panel.

| Parts No. | Description |
|-----------|-------------|
| AXX-193 | 220 V label |
| AXX-192 | 240 V label |


| | |
|-----------|---------|
| X1 | CN351 |
| KU | 33 pins |
| HEM,SD,HB | 31 pins |

KU TYPE ONLY




1. This P.C.B. connection diagram is viewed from the parts mounted side.
2. The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the above Table.
3. The capacitor terminal marked with shows negative terminal.
4. The diode marked with shows cathode side.
5. The transistor terminal marked with shows emitter.

MAIN BOARD ASSEMBLY




| | | | | | | | |
|------|-------|-------|------|-------|-------|------|------|
| Q101 | IC202 | Q240 | Q51 | IC14 | IC13 | IC12 | IC11 |
| Q321 | | IC151 | IC32 | IC201 | IC31 | | IC30 |
| | | | | Q241 | IC331 | | Q391 |


POWER SUPPLY SECTION FOR KU TYPE



POWER SUPPLY SECTION FOR HB AND HEM TYPES




POWER SUPPLY SECTION FOR SD TYPE



This P.C.B. connection diagram is viewed from the foil side.

(PWWME44:HB TYPE)
(PWWME43:KU MEM AND 2D TYPES)
ANALOG BOARD ASSEMBLY

[illegible]


2520
4520
1520

0253 0255 0259 0258 0251 0252 0254 0256 0257 0250

৯৯০

02525 02527 1C213
02501 02503 1C225
02505 02507 1C253
02503


ANALOG BOARD ASSEMBLY (PWM1643 : KU HEM AND SD TYPES) (PWM1644 : HB TYPE)



IC620 IC602
IC621
IC601

Q525 Q554 IC501 Q559
Q524 Q556 IC522 Q558
Q521 Q523 IC554
Q522
IC512

Q562 Q555 Q560 IC502 Q563
Q557 Q561 IC523
IC513 IC555





SERVICE GUIDE

ORDER NO.
ARP2318

COMPACT DISC PLAYER

PD-41

PD-9700

PD-31

PD-8700

PD-8700-S

PD-7700

PD-7700-S

- For information on performing repair works, refer to the respective service manuals, ARP2297(PD-41, PD-9700) and ARP2228(PD-31, PD-8700, PD-8700-S, PD-7700, PD-7700-S).

CONTENTS

- 1. DISASSEMBLY 2
- 2. MECHANISM DESCRIPTION 7

PIONEER ELECTRONIC CORPORATION 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan
PIONEER ELECTRONICS SERVICE INC. P.O. Box 1760, Long Beach, California 90801 U.S.A.
PIONEER ELECTRONICS OF CANADA, INC. 505 Cochrane Drive, Markham, Ontario L3R 8E3 Canada
PIONEER ELECTRONIC [EUROPE] N.V. Keetberglaan 1, 9120 Beveren, Belgium
PIONEER ELECTRONICS AUSTRALIA PTY. LTD. 178-184 Boundary Road, Braeside, Victoria 3195, Australia TEL: [03] 580-9911
© **PIONEER ELECTRONIC CORPORATION 1991**

FI JUL. 1991


1. DISASSEMBLY

1.1 DISASSEMBLING LOADING MECHANISM ASSEMBLY


Tray Removal

- ① Open the tray all the way.

Note : If you slide the right cam and the left cam in the direction of the arrow, you can open the tray by hand.




- ② While pressing the plastic springs section (A) at the rear of the tray left and right at the same time, pull out the tray.




Float Base Assembly Removal

- ① Remove the tray.
- ② Move the right and left cams in the direction of their respective (A) arrows until the protrusions of the loading base come to the slit opening of the right cam and the left cam.
- ③ Pull up the float base assembly and remove it from the loading base.



Turntable Assembly Removal


- ① Remove the two screws from the rear of the tray and remove the two table guides.
- ② Turn the table bearing assembly in the direction of the **A** arrow.
- ③ At the position where the tray protrusion is lined up with the table bearing assembly notch (the position shown in the figure), remove the turntable assembly.



1.2 ASSEMBLING THE LOADING MECHANISM ASSEMBLY


Assembling the Tray Assembly

- ① Place the turntable assembly upside down and place the compression spring in its center.
- ② Line up the notch section of the turntable assembly with the protrusion section of the tray and assemble.




Note: The turntable assembly is to be in the position shown in the figure.

- ③ After assembling the turntable assembly and the tray, turn the lock plate pin somewhat in the direction of the (B) arrow, then hold with your finger.
- ④ While still holding the lock plate pin with your finger, turn the table bearing assembly in the direction of the (A) arrow until the holes in the float rubber piece and in the tray are lined up with each other.
- ⑤ Use the two screws to install the two table guides into the lines up tray and float rubber piece holes.




Drive Gear, Timing lever, Gear Pulley, Switch Head, and Lever Switch Installation

- ① Install each part on the loading base as shown in the figure.




Loading Base Assembly, Float Base Assembly, Right Cam, and Left Cam Installation

- ① Place the float base assembly upside down (with the pickup facing up).
- ② Install the right cam and the left cam on the float base assembly. Position each cam all the way in the direction of its respective arrow.




- ③ Line up the Δ marks on the drive gear and the loading base as shown in the figure.
- ④ Line up the Σ marks on the loading base and the timing lever pin as shown in the figure.




- ⑤ Next, finely adjust the timing lever angle and the left and right cam position and insert the loading base protrusion A sections (two each on the left and right) into the A' openings on the left and right cam.

At the same time, pass the protrusion B sections on the left and right cam (one on each cam) through the loading base slit and insert into the B' holes on the timing lever.





Tray Installation

- ① Place the parts assembled in the last section upside down.
- ② While being careful not to knock the loading base, drive gear, and timing lever pin aligned in the last section out of place, insert the tray.




Motor and Switch Wiring and Styling



Assembling the Motor Assembly

Set the gap between the motor and pulley to 7.0 mm.



2. MECHANISM DESCRIPTION

2.1 MECHANISM SUMMARY

Summary

This mechanism is a single mechanism assembly with a turntable mounted.

Mechanism Sections

This mechanism comprises the loading section and the servo mechanism section.

Loading Section

The loading section opens and closes the tray and provides the clamping for the servo mechanism up/down movement. As a new test, this mechanism has a mechanism for decelerating smoothly at the completion of tray take-in in order to make the tray movement look smooth. This done by a spiral shaped drive gear (PNW1996) and the irregularly shaped rack on the tray.


The spring-type clamp quiets the clamping.

Servo Mechanism Section

The basic structure of the servo mechanism is about the same as that for a multi-disc type servo mechanism, but the use of the spring-type clamp makes a turntable magnet unnecessary.

The lever switch (DSK1003) and the switch head (PNW1999) are used to detect the completion of tray opening by means of the protrusion on the tray (PNW 2003) rear surface and clamp completion is detected using the timing lever (PNW1997) side wall.

When it is pressed by the protrusion on the rear surface of the tray, the switch head goes into condition ②.



2.2 OPERATION SUMMARY

This explanation covers operations sequentially from the disc take-in state to the completion of tray opening.


1. Clamp Condition

This explanation starts from the tray assembly.

The turntable in the tray assembly always turns freely, but the height of the turntable is locked while the tray is open. This lock is released by the clamping.

This is because while the tray is open, the table bearing that receives the turntable is locked by the lock plate. Just before the completion of tray take-in, the lock plate is turned to release the lock.

Next, we will explain the clamping. When the lock on the table bearing is released, the turntable is supported from below by the float spring. During clamping, the amount of deflection of the spring generates an upward load to provide the clamping force.



2. Clamp Release


When the timing lever turns, the left and right cams move forward and backward respectively to lift up the float base and release the clamp.

3. Tray Operation

The tray and timing lever have rack sections and these rack sections have notch teeth.

Both mesh with the drive gear, but only one tooth meshes at a time, so normally only one of the rack sections is meshed with the drive gear at a time. The rack section pull-in and separation are synchronized with the timing lever pin and the corresponding tray guide groove. When the servo mechanism separates from the turntable, the tray is pushed out by the timing lever pin and the tray rack meshes with the drive gear. The tray is driven by the drive gear and moves forward while turning the timing lever and releasing the meshing with the drive gear.


The tray deceleration mechanism mentioned earlier causes the tray to accelerate gradually when it starts to open and causes the tray to decelerate smoothly to the completion of take-in when it closes.



XQ
373

3377

Service Manual



ORDER NO.
ARP2297

COMPACT DISC PLAYER

PD-41

PD-9700

PD-41 AND PD-9700 HAVE THE FOLLOWING :

| Type | Model | | Power Requirement | Remarks |
|------|-------|---------|--|---------|
| | PD-41 | PD-9700 | | |
| KU | ○ | — | AC 120 V only | |
| KC | — | ○ | AC 120 V only | |
| HEM | — | ○ | AC 220 V-230 V, AC 230 V-240 V (switchable)* | |
| HB | — | ○ | AC 220 V-230 V, AC 230 V-240 V (switchable)* | |
| SD | — | ○ | AC 110 V, 120 V-127 V, 220 V, 240 V (switchable) | |

* Change the connection of the power transformer's primary wiring.

- This manual is applicable to PD-41/KU, PD-9700/KC, HEM, HB and SD types.
- As to the PD-9700/KC, HEM, HB and SD types, refer to page 84.
- As to the disassembly and mechanism descriptions, refer to the PD-41, PD-9700 service guide(ARP2318).
- Ce manuel pour le service comprend les explications de réglage en français.
- Este manual de servicio trata del método ajuste escrito en español.

CONTENTS

| | | | |
|--|----|---|----|
| 1. SAFETY INFORMATION | 2 | 6. RÉGLAGE | 50 |
| 2. EXPLODED VIEWS AND PARTS LIST | 4 | 6. AJUSTE | 66 |
| 3. PACKING | 11 | 7. IC INFORMATION | 82 |
| 4. SCHEMATIC DIAGRAM AND | 12 | 8. FOR PD-9700/KC, HEM, HB AND SD TYPES | 84 |
| P.C.BOARDS CONNECTION DIAGRAM | | 9. PANEL FACILITIES | 86 |
| 5. P.C.B's PARTS LIST | 32 | 10. SPECIFICATIONS | 88 |
| 6. ADJUSTMENTS | 35 | | |

3377

This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING

Lead in solder used in this product is listed by the California Health and Welfare agency as a known reproductive toxicant which may cause birth defects or other reproductive harm (California Health & Safety Code, Section 25249.5).

When servicing or handling circuit boards and other components which contain lead in solder, avoid unprotected skin contact with the solder. Also, when soldering do not inhale any smoke or fumes produced.

1. SAFETY INFORMATION


(FOR USA MODEL ONLY)

1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120V AC 60Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5mA.



ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a Δ on the schematics and on the parts list in this Service Manual. The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

(FOR EUROPEAN MODEL ONLY)

VARO!

AVATTAESSA JA SUOJALUKITUS
OHITETTAESSA OLET ALTTIINA
NÄKYMÄTTÖMÄLLE LASERSÄTEILYLLE.
ÄLÄ KATSO SÄTEESEEN.

ADVERSEL:

USYNLIG LASERSTRÅLING VED ÅBNING
NÅR SIKKERHEDSAFBRYDERE ER UDE AF
FUNKTION UNDGA UDSÆTTELSE FOR
STRÅLING.

WARNING!

OSYNLIG LASERSTRÅLNING NÅR DENNA
DEL ÄR ÖPPNAD OCH SPÄRREN
ÄR URKOPPLAD. BETRAKTA EJ STRÅLEN.



LASER
Kuva 1
Lasersäteilyn
varoituserkki

WARNING!

DEVICE INCLUDES LASER DIODE WHICH
EMITS INVISIBLE INFRARED RADIATION
WHICH IS DANGEROUS TO EYES. THERE IS
A WARNING SIGN ACCORDING TO PICTURE
1 INSIDE THE DEVICE CLOSE TO THE LASER
DIODE.



LASER
Picture 1
Warning sign for
laser radiation

IMPORTANT

THIS PIONEER APPARATUS CONTAINS
LASER OF HIGHER CLASS THAN 1.
SERVICING OPERATION OF THE APPARATUS
SHOULD BE DONE BY A SPECIALLY
INSTRUCTED PERSON.

LASER DIODE CHARACTERISTICS


MAXIMUM OUTPUT POWER: 5 mw
WAVELENGTH: 780-785 nm

LABEL CHECK


HEM type



HEM and HB types



HB type



HEM type

Additional Laser Caution

1. Laser Interlock Mechanism

The position of the switch (S 601) for the detecting loading completion is detected by the system microprocessor, and the design prevents laser diode oscillation when the switch (S 601) is not in CLMP terminal side (when the mechanism is not clamped and CLMP signal is high level).

Thus, the interlock will no longer function if the switch (S 601) is deliberately set to CLMP terminal side (if CLMP signal is low level).

In the test mode, the interlock mechanism will not function (refer to page 36).

Laser diode oscillation will continue if pins 2 and 3 of CXA 1471 S (IC 101) are connected to ground or pin 20 is connected to high level (ON) or the terminals of Q 101 are shorted to each other (fault condition).

2. When the cover is opened, close viewing of the objective lens with the naked eye will cause exposure to a Class 1 or higher laser beam.

2. EXPLODED VIEWS AND PARTS LIST

NOTES :

- Parts without part number cannot be supplied.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

2.1 EXTERIOR

Parts List of Exterior

| Mark | No. | Description | Parts No. | Mark | No. | Description | Parts No. |
|------|-----|-----------------------|--------------|------|-----|---------------------------|-----------|
| ⚠● | 1 | Analog board assembly | PWM1490 | ⚠● | 41 | Bonnet case | PYY1071 |
| ⚠ | 2 | Strain relief | CM-22C | ⚠● | 42 | Main board assembly | PWZ2150 |
| | 3 | 33P F.F.C/30V | PDD1094 | ● | 43 | Function A board assembly | PWZ2168 |
| ⚠ | 4 | AC power cord | PDG1015 | | 44 | Badge | |
| ⚠ | 5 | Power transformer | PTT1166 | | 45 | Front panel | |
| ⚠ | 6 | Power transformer | PTT1206 | | 46 | Function B board assembly | |
| | 7 | Washer | ABE1009 | | 47 | Primary board assembly | |
| | 8 | Stopper | PNM1095 | | 48 | Rubber sheet | |
| | 9 | Tape | PNM1099 | | 49 | Switch angle | |
| | 10 | Stopper | PNM1107 | | 50 | Spacer | |
| | 11 | Cord clasper(steel) | RNH-184 | | 51 | L angle | |
| | 12 | Button | PAC1530 | | 52 | Sheet | |
| | 13 | Power button | PAC1539 | | 53 | Tape | |
| | 14 | Control button | PAC1609 | | 54 | Side angle | |
| | 15 | FL sheet | PAM1514 | | 55 | PCB angle | |
| | 16 | Display window | PAM1515 | | 56 | Under base | |
| | 17 | LED cover | PEB1150 | | 57 | Base | |
| | 18 | LED cover (S) | PEB1167 | | 58 | Rear base | |
| | 19 | Side rubber | PEB1180 | | 59 | Binder holder | |
| | 20 | Tray panel | PNW1815 | | 60 | PCB spacer | |
| | 21 | Lens L | PNW1860 | | 61 | Angle B | |
| | 22 | Indicator lens | PNW1893 | | 62 | Shield angle | |
| | 23 | Tray lens | PNW1950 | | 63 | Shield plate | |
| | 24 | Control panel | PNW2066 | | | | |
| | 25 | | | | | | |
| | 26 | Screw | BBT30P080FCC | | | | |
| | 27 | Screw | BBZ26P080FCC | | | | |
| | 28 | Screw | BBZ30P080FCC | | | | |
| | 29 | Screw | BBZ30P080FCC | | | | |
| | 30 | Screw | BBZ30P140FCC | | | | |
| | 31 | Screw | BBZ40P060FCC | | | | |
| | 32 | Screw | BBZ40P080FZK | | | | |
| | 33 | Screw | FBT40P080FZK | | | | |
| | 34 | Screw | IBZ30P060FCC | | | | |
| | 35 | Screw | IBZ30P150FCC | | | | |
| | 36 | Screw | IBZ30P180FCC | | | | |
| | 37 | Screw | PDZ30P050FCC | | | | |
| | 38 | Screw | PMZ30P060FCC | | | | |
| | 39 | Washer | WH40FUC | | | | |
| | 40 | Front panel assembly | PEA1167 | | | | |

A

B

C


D

A


B

C

D



2.2 MECHANISM SECTION



FUNCTION A BOARD ASSEMBLY
(PWZ2168:KU AND KC TYPES)
(PWZ2169:HEM,SD AND HB TYPES)

| X2 | |
|-------------|--------|
| KU, KC | 33pins |
| HB, HEM, SD | 31pins |





KU AND KC
TYPES ONLY

| IC301 (CXD2500AQ) | | | |
|-------------------|---------|---------|---------|
| Pin No. | Voltage | Pin No. | Voltage |
| 1 | 5 | 41 | 2.5 |
| 2 | 2.1 | 42 | 5 |
| 3 | 5 | 43 | 2.5 |
| 4 | 2.6 | 44 | 0 |
| 5 | 2.2 | 45 | 5 |
| 6 | 5 | 46 | 4.4 |
| 7 | 0 | 47 | 0 |
| 8 | 5 | 48 | 0 |
| 9 | 0 | 49 | 0~0.3 |
| 10 | 0 | 50 | 1.2 |
| 11 | 2.1 | 51 | 1.2 |
| 12 | 0 | 52 | 0 |
| 13 | 1.0 | 53 | 2.5 |
| 14 | 0.9~1.3 | 54 | 2.5 |
| 15 | 0 | 55 | 0 |
| 16 | 2.0 | 56 | 2.9 |
| 17 | 0 | 57 | 2.5 |
| 18 | 2.5 | 58 | 5 |
| 19 | 2.4 | 59 | 5 |
| 20 | 2.4 | 60 | 2.5 |
| 21 | 0 | 61 | 0 |
| 22 | 2.5 | 62 | 2.5 |
| 23 | 5 | 63 | 0 |
| 24 | 2.5 | 64 | 0 |
| 25 | 0.2 | 65 | 0 |
| 26 | 0 | 66 | 3.3~4.6 |
| 27 | 2.5 | 67 | 5 |
| 28 | 0 | 68 | 0 |
| 29 | 0 | 69 | 2.1~3 |
| 30 | 0 | 70 | 5 |
| 31 | 1.3~2.2 | 71 | 5 |
| 32 | 2.5 | 72 | 5 |
| 33 | 5 | 73 | 5 |
| 34 | 2.5 | 74 | 5 |
| 35 | 2.5 | 75 | 5 |
| 36 | 2.5 | 76 | 0 |
| 37 | 2.5 | 77 | 5 |
| 38 | 2.5 | 78 | 5 |
| 39 | 0 | 79 | 5 |
| 40 | 5 | 80 | 0 |

| IC151 (CXA1372S) | | | |
|------------------|---------|---------|---------|
| Pin No. | Voltage | Pin No. | Voltage |
| 1 | 0 | 25 | -5 |
| 2 | 0 | 26 | 5 |
| 3 | 0 | 27 | 5 |
| 4 | 0 | 28 | 5 |
| 5 | 0 | 29 | 5 |
| 6 | 0 | 30 | 5 |
| 7 | 0 | 31 | 5 |
| 8 | 0 | 32 | 0 |
| 9 | 0 | 33 | 5 |
| 10 | 0 | 34 | 0 |
| 11 | 1 | 35 | 0 |
| 12 | 0 | 36 | -5 |
| 13 | 0.2 | 37 | 2.5 |
| 14 | 0 | 38 | 2.5 |
| 15 | 0 | 39 | 5 |
| 16 | 5 | 40 | -1.5 |
| 17 | 0 | 41 | -1.7 |
| 18 | 0 | 42 | 5 |
| 19 | 0 | 43 | -0.7 |
| 20 | 0.2~0.8 | 44 | -1.6 |
| 21 | 0 | 45 | 0 |
| 22 | -4 | 46 | 0.8 |
| 23 | 1.3 | 47 | -5 |
| 24 | 0 | 48 | 0 |

| IC401 (PD4329A) | | | | | | | |
|-----------------|-------------|---------|-------------|---------|---------|---------|---------|
| Pin No. | Voltage | Pin No. | Voltage | Pin No. | Voltage | Pin No. | Voltage |
| 1 | -24~-24.3 | 17 | -1 | 33 | 5 | 49 | 5 |
| 2 | -24~-24.3 | 18 | -2.6 | 34 | 3.3~4.7 | 50 | 5 |
| 3 | -24~-24.3 | 19 | -5 | 35 | 5 | 51 | 0 |
| 4 | -24~-24.3 | 20 | -17.6~-17.8 | 36 | 0 | 52 | 5 |
| 5 | -24~-24.3 | 21 | -1.6 | 37 | 5 | 53 | 5 |
| 6 | -24~-24.3 | 22 | -12.5~-15.5 | 38 | 5 | 54 | 5 |
| 7 | -24~-24.3 | 23 | -3.4~-6.4 | 39 | 0 | 55 | 5 |
| 8 | -24~-24.3 | 24 | -4~-7 | 40 | 0 | 56 | 2.5 |
| 9 | -24~-24.3 | 25 | -6.8~-9.8 | 41 | 0 | 57 | 2.5 |
| 10 | -24~-24.3 | 26 | 5 | 42 | 0 | 58 | 0 |
| 11 | -24~-24.3 | 27 | -1.5 | 43 | 5 | 59 | 0 |
| 12 | 0 | 28 | -1.2~-1.6 | 44 | 5 | 60 | 5 |
| 13 | 5 | 29 | -12.5~-15.4 | 45 | 0 | 61 | 0 |
| 14 | 0 | 30 | -12.1~-17.6 | 46 | 5 | 62 | 0 |
| 15 | 4.9 | 31 | 4 | 47 | 5 | 63 | 0 |
| 16 | -27.5~-27.8 | 32 | 5 | 48 | 2.1~3 | 64 | 0 |

FUNCTION B BOARD
ASSEMBLY



Line Voltage Selection (For HEM and HB types)

Line voltage can be changed with the following steps.

1. Disconnect the AC power cord.
2. Remove the top cover.
3. Change the position of the jumper wire A as follows


| Voltage | Jumper wire A position |
|-------------|------------------------|
| 220 V-230 V | a |
| 230 V-240 V | b |

4. Stick the line voltage label on the rear panel.

| Parts No. | Description |
|-----------|-------------|
| AXX-193 | 220 V label |
| AXX-192 | 240 V label |

| X1 | |
|-------------|--------|
| KU, KC | 33pins |
| HB, HEM, SD | 31pins |

KU AND KC TYPES ONLY



•TERMINAL VOLTAGES

| | | | | | | | | | | | |
|---------|----|-----|-----|-----|------|------|-----|------|-----|----|----|
| Pin No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 |
| Voltage | 0 | 1.2 | 2.9 | 1.3 | -0.9 | -4.7 | 1.4 | -0.7 | 1.5 | 0 | 0 |
| Pin No. | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 |
| Voltage | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

IC101 (CXA1471S)

| | | | | | | | | | | | | | | | | |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| Pin No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| Voltage | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Pin No. | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |
| Voltage | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

IC151 (CXA1372S)

| | | | | | | | | | | | | | | | | | | | | |
|---------|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| Pin No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| Voltage | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Pin No. | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |
| Voltage | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

IC301 (CXD2500AQ)

3. PACKING

| Mark | No. | Description | Parts No. |
|------|-----|---|-----------|
| | 1 | Cord with plug(mini plug) | PDE-319 |
| | 2 | Cord with plug | PDE1001 |
| | 3 | Operating instructions (English, French) | PRE1149 |
| | 4 | Remote control unit(CU-PD054) | PWW1058 |
| | 5 | Battery cover | PZN1001 |
| | 6 | Polyethelene bag | Z21-038 |
| | 7 | Protector F | PHA1145 |
| | 8 | Protector R | PHA1146 |
| | 9 | CD packing case | PHG1677 |
| | 10 | Sheet | VHL-037 |
| | 11 | Label | PRW1253 |

101 Battery (R03, AAA)




Fig. 1




Fig. 2




Fig. 3






















Fig. 5



4. SCHEMATIC DIAGRAM AND P.C.BOARDS CONNECTION DIAGRAM

4.1 MAIN BOARD(PWZ 2150), PRIMARY BOARD, FUNCTION A BOARD(PWZ 2168), AND FUNCTION B BOARD ASSEMBLIES





| | |
|-------------|-----------|
| *1 | CN401 |
| KU, KC | HLEM33S-1 |
| HEM, HB, SD | HLEM31S-1 |

*1 KU, KC ONLY

EXCEPT KU, KC

IC402 SBX1610-51

Vout Vcc GND

C405 0.01

GND

V+5

C402 470/16

GND

GND

V+5

C403 0.01

GND

GND

V+5

C404 470/16

GND

GND

V+5

C405 0.01

GND

GND

V+5

C406 470/16

GND

GND

V+5

C407 470/16

GND

GND

V+5

C408 470/16

GND

GND

V+5

C409 470/16

GND

GND

V+5

C410 470/16

GND

GND

V+5

C411 470/16

GND

GND

V+5

C412 470/16

GND

GND

V+5

C413 470/16

GND

GND

V+5

C414 470/16

GND

GND

V+5

C415 470/16

GND

GND

V+5

C416 470/16

GND

GND

V+5

C417 470/16

GND

GND

V+5

C418 470/16

GND

GND

V+5

C419 470/16

GND

GND

V+5

C420 470/16

GND

GND

V+5

C421 470/16

GND

GND

V+5

C422 470/16

GND

GND

V+5

C423 470/16

GND

GND

V+5

C424 470/16

GND

GND

V+5

C425 470/16

GND

GND

V+5

C426 470/16

GND

GND

V+5

C427 470/16

GND

GND

V+5

C428 470/16

GND

GND

V+5

C429 470/16

GND

GND

V+5

C430 470/16

GND

GND

V+5

C431 470/16

GND

GND

V+5

C432 470/16

GND

GND

V+5

C433 470/16

GND

GND

V+5

C434 470/16

GND

GND

V+5

C435 470/16

GND

GND

V+5

C436 470/16

GND

GND

V+5

C437 470/16

GND

GND

V+5

C438 470/16

GND

GND

V+5

C439 470/16

GND

GND

V+5

C440 470/16

GND

GND

V+5

C441 470/16

GND

GND

V+5

C442 470/16

GND

GND

V+5

C443 470/16

GND

GND

V+5

C444 470/16

GND

GND

V+5

C445 470/16

GND

GND

V+5

C446 470/16

GND

GND

V+5

C447 470/16

GND

GND

V+5

C448 470/16

GND

GND

V+5

C449 470/16

GND

GND

V+5

C450 470/16

GND

GND

V+5

C451 470/16

GND

GND

V+5

C452 470/16

GND

GND

V+5

C453 470/16

GND

GND

V+5

C454 470/16

GND

GND

V+5

C455 470/16

GND

GND

V+5

C456 470/16

GND

GND

V+5

C457 470/16

GND

GND

V+5

C458 470/16

GND

GND

V+5

C459 470/16

GND

GND

V+5

C460 470/16

GND

GND

V+5

C461 470/16

GND

GND

V+5

C462 470/16

GND

GND

V+5

C463 470/16

GND

GND

V+5

C464 470/16

GND

GND

V+5

C465 470/16

GND

GND

V+5

C466 470/16

GND

GND


V+5

C467 470/16

MAIN BOARD ASSEMBLY
(PWZ2150:KU AND KC TYPES)
(PWZ2151:HEM AND SD TYPES)
(PWZ2153:HB TYPE)

IC151 (CXA1372S)


| Pin No. | Voltage | Pin No. | Voltage |
|---------|---------|---------|---------|
| 1 | 0 | 25 | -5 |
| 2 | 0 | 26 | 5 |
| 3 | 0 | 27 | 5 |
| 4 | 0 | 28 | 5 |
| 5 | 0 | 29 | 5 |
| 6 | 0 | 30 | 5 |
| 7 | 0 | 31 | 5 |
| 8 | 0 | 32 | 0 |
| 9 | 0 | 33 | 5 |
| 10 | 0 | 34 | 0 |
| 11 | 1 | 35 | 0 |
| 12 | 0 | 36 | -5 |
| 13 | 0.2 | 37 | 2.5 |
| 14 | 0 | 38 | 2.5 |
| 15 | 0 | 39 | 5 |
| 16 | 5 | 40 | -1.5 |
| 17 | 0 | 41 | -1.7 |
| 18 | 0 | 42 | 5 |
| 19 | 0 | 43 | -0.7 |
| 20 | 0.2-0.8 | 44 | -1.6 |
| 21 | 0 | 45 | 0 |
| 22 | -4 | 46 | 0.8 |
| 23 | 1.3 | 47 | -5 |
| 24 | 0 | 48 | 0 |




IC202 Q240 IC151 IC201 IC31 IC331 IC30
Q51 IC32 Q241 Q391
IC14 IC13 IC12 IC11

TO ANALOG BOARD ASSEMBLY


POWER SUPPLY SECTION FOR KU AND KC TYPES



POWER SUPPLY SECTION FOR HB AND HEM TYPES



POWER SUPPLY SECTION FOR SD TYPE



A

B

C

D

This P.C.B. connection diagram is viewed from the foil side.




| | |
|-----------|--------|
| HB'HEW,2D | 34pins |
| KU, KC | 33pins |
| CN381 | |

KU AND KC TYPES ONLY


VR151 VR152
VR103 VR105

IC101 IC301 IC302 IC303 IC304 IC401 IC402 IC403 IC404 IC405

IC505 Q5A



ASSEMBLY
FUNCTION B BOARD



(PW2169:HEM,2D AND HB TYPES)
FUNCTION A BOARD ASSEMBLY
(PW2168:KU AND KC TYPES)

| Pin | No. | Pin | No. | Pin | No. | Pin | No. | Pin | No. |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 1 | 18 | 1 | 18 | 1 | 18 | 1 | 18 | 1 | 18 |
| 2 | 17 | 2 | 17 | 2 | 17 | 2 | 17 | 2 | 17 |
| 3 | 16 | 3 | 16 | 3 | 16 | 3 | 16 | 3 | 16 |
| 4 | 15 | 4 | 15 | 4 | 15 | 4 | 15 | 4 | 15 |
| 5 | 14 | 5 | 14 | 5 | 14 | 5 | 14 | 5 | 14 |
| 6 | 13 | 6 | 13 | 6 | 13 | 6 | 13 | 6 | 13 |
| 7 | 12 | 7 | 12 | 7 | 12 | 7 | 12 | 7 | 12 |
| 8 | 11 | 8 | 11 | 8 | 11 | 8 | 11 | 8 | 11 |
| 9 | 10 | 9 | 10 | 9 | 10 | 9 | 10 | 9 | 10 |
| 10 | 9 | 10 | 9 | 10 | 9 | 10 | 9 | 10 | 9 |
| 11 | 8 | 11 | 8 | 11 | 8 | 11 | 8 | 11 | 8 |
| 12 | 7 | 12 | 7 | 12 | 7 | 12 | 7 | 12 | 7 |
| 13 | 6 | 13 | 6 | 13 | 6 | 13 | 6 | 13 | 6 |
| 14 | 5 | 14 | 5 | 14 | 5 | 14 | 5 | 14 | 5 |
| 15 | 4 | 15 | 4 | 15 | 4 | 15 | 4 | 15 | 4 |
| 16 | 3 | 16 | 3 | 16 | 3 | 16 | 3 | 16 | 3 |
| 17 | 2 | 17 | 2 | 17 | 2 | 17 | 2 | 17 | 2 |
| 18 | 1 | 18 | 1 | 18 | 1 | 18 | 1 | 18 | 1 |

| | |
|-----------|--------|
| HB'HEW,2D | 34pins |
| KU, KC | 33pins |
| CN401 | |



KU AND KC
TYPES ONLY

IC401 IC402 IC403 IC404 IC405

| Pin | No. | Pin | No. | Pin | No. | Pin | No. | Pin | No. |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 1 | 18 | 1 | 18 | 1 | 18 | 1 | 18 | 1 | 18 |
| 2 | 17 | 2 | 17 | 2 | 17 | 2 | 17 | 2 | 17 |
| 3 | 16 | 3 | 16 | 3 | 16 | 3 | 16 | 3 | 16 |
| 4 | 15 | 4 | 15 | 4 | 15 | 4 | 15 | 4 | 15 |
| 5 | 14 | 5 | 14 | 5 | 14 | 5 | 14 | 5 | 14 |
| 6 | 13 | 6 | 13 | 6 | 13 | 6 | 13 | 6 | 13 |
| 7 | 12 | 7 | 12 | 7 | 12 | 7 | 12 | 7 | 12 |
| 8 | 11 | 8 | 11 | 8 | 11 | 8 | 11 | 8 | 11 |
| 9 | 10 | 9 | 10 | 9 | 10 | 9 | 10 | 9 | 10 |
| 10 | 9 | 10 | 9 | 10 | 9 | 10 | 9 | 10 | 9 |
| 11 | 8 | 11 | 8 | 11 | 8 | 11 | 8 | 11 | 8 |
| 12 | 7 | 12 | 7 | 12 | 7 | 12 | 7 | 12 | 7 |
| 13 | 6 | 13 | 6 | 13 | 6 | 13 | 6 | 13 | 6 |
| 14 | 5 | 14 | 5 | 14 | 5 | 14 | 5 | 14 | 5 |
| 15 | 4 | 15 | 4 | 15 | 4 | 15 | 4 | 15 | 4 |
| 16 | 3 | 16 | 3 | 16 | 3 | 16 | 3 | 16 | 3 |
| 17 | 2 | 17 | 2 | 17 | 2 | 17 | 2 | 17 | 2 |
| 18 | 1 | 18 | 1 | 18 | 1 | 18 | 1 | 18 | 1 |

| Pin | No. | Pin | No. | Pin | No. | Pin | No. | Pin | No. |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 1 | 18 | 1 | 18 | 1 | 18 | 1 | 18 | 1 | 18 |
| 2 | 17 | 2 | 17 | 2 | 17 | 2 | 17 | 2 | 17 |
| 3 | 16 | 3 | 16 | 3 | 16 | 3 | 16 | 3 | 16 |
| 4 | 15 | 4 | 15 | 4 | 15 | 4 | 15 | 4 | 15 |
| 5 | 14 | 5 | 14 | 5 | 14 | 5 | 14 | 5 | 14 |
| 6 | 13 | 6 | 13 | 6 | 13 | 6 | 13 | 6 | 13 |
| 7 | 12 | 7 | 12 | 7 | 12 | 7 | 12 | 7 | 12 |
| 8 | 11 | 8 | 11 | 8 | 11 | 8 | 11 | 8 | 11 |
| 9 | 10 | 9 | 10 | 9 | 10 | 9 | 10 | 9 | 10 |
| 10 | 9 | 10 | 9 | 10 | 9 | 10 | 9 | 10 | 9 |
| 11 | 8 | 11 | 8 | 11 | 8 | 11 | 8 | 11 | 8 |
| 12 | 7 | 12 | 7 | 12 | 7 | 12 | 7 | 12 | 7 |
| 13 | 6 | 13 | 6 | 13 | 6 | 13 | 6 | 13 | 6 |
| 14 | 5 | 14 | 5 | 14 | 5 | 14 | 5 | 14 | 5 |
| 15 | 4 | 15 | 4 | 15 | 4 | 15 | 4 | 15 | 4 |
| 16 | 3 | 16 | 3 | 16 | 3 | 16 | 3 | 16 | 3 |
| 17 | 2 | 17 | 2 | 17 | 2 | 17 | 2 | 17 | 2 |
| 18 | 1 | 18 | 1 | 18 | 1 | 18 | 1 | 18 | 1 |

POWER TRANSFORMER
TO



TO MAIN BOARD
ASSEMBLY

TO MAIN BOARD
ASSEMBLY

| no. of Volts | no. of Volts | no. of Volts | no. of Volts |
|--------------------|--------------------|--------------------|--------------------|
| 1 | 0 | 1 | 2 |
| 2 | 0 | 1 | 2 |
| 3 | 0 | 1 | 2 |
| 4 | 0 | 1 | 2 |
| 5 | 0 | 1 | 2 |
| 6 | 0 | 1 | 2 |
| 7 | 0 | 1 | 2 |
| 8 | 0 | 1 | 2 |
| 9 | 0 | 1 | 2 |
| 10 | 0 | 1 | 2 |
| 11 | 0 | 1 | 2 |
| 12 | 0 | 1 | 2 |
| 13 | 0 | 1 | 2 |
| 14 | 0 | 1 | 2 |
| 15 | 0 | 1 | 2 |
| 16 | 0 | 1 | 2 |
| 17 | 0 | 1 | 2 |
| 18 | 0 | 1 | 2 |
| 19 | 0 | 1 | 2 |
| 20 | 0 | 1 | 2 |
| 21 | 0 | 1 | 2 |
| 22 | 0 | 1 | 2 |
| 23 | 0 | 1 | 2 |
| 24 | 0 | 1 | 2 |
| 25 | 0 | 1 | 2 |
| 26 | 0 | 1 | 2 |
| 27 | 0 | 1 | 2 |
| 28 | 0 | 1 | 2 |
| 29 | 0 | 1 | 2 |
| 30 | 0 | 1 | 2 |
| 31 | 0 | 1 | 2 |
| 32 | 0 | 1 | 2 |
| 33 | 0 | 1 | 2 |
| 34 | 0 | 1 | 2 |
| 35 | 0 | 1 | 2 |
| 36 | 0 | 1 | 2 |
| 37 | 0 | 1 | 2 |
| 38 | 0 | 1 | 2 |
| 39 | 0 | 1 | 2 |
| 40 | 0 | 1 | 2 |
| 41 | 0 | 1 | 2 |
| 42 | 0 | 1 | 2 |
| 43 | 0 | 1 | 2 |
| 44 | 0 | 1 | 2 |
| 45 | 0 | 1 | 2 |
| 46 | 0 | 1 | 2 |
| 47 | 0 | 1 | 2 |
| 48 | 0 | 1 | 2 |
| 49 | 0 | 1 | 2 |
| 50 | 0 | 1 | 2 |
| 51 | 0 | 1 | 2 |
| 52 | 0 | 1 | 2 |
| 53 | 0 | 1 | 2 |
| 54 | 0 | 1 | 2 |
| 55 | 0 | 1 | 2 |
| 56 | 0 | 1 | 2 |
| 57 | 0 | 1 | 2 |
| 58 | 0 | 1 | 2 |
| 59 | 0 | 1 | 2 |
| 60 | 0 | 1 | 2 |
| 61 | 0 | 1 | 2 |
| 62 | 0 | 1 | 2 |
| 63 | 0 | 1 | 2 |
| 64 | 0 | 1 | 2 |
| 65 | 0 | 1 | 2 |
| 66 | 0 | 1 | 2 |
| 67 | 0 | 1 | 2 |
| 68 | 0 | 1 | 2 |
| 69 | 0 | 1 | 2 |
| 70 | 0 | 1 | 2 |
| 71 | 0 | 1 | 2 |
| 72 | 0 | 1 | 2 |
| 73 | 0 | 1 | 2 |
| 74 | 0 | 1 | 2 |
| 75 | 0 | 1 | 2 |
| 76 | 0 | 1 | 2 |
| 77 | 0 | 1 | 2 |
| 78 | 0 | 1 | 2 |
| 79 | 0 | 1 | 2 |
| 80 | 0 | 1 | 2 |
| 81 | 0 | 1 | 2 |
| 82 | 0 | 1 | 2 |
| 83 | 0 | 1 | 2 |
| 84 | 0 | 1 | 2 |
| 85 | 0 | 1 | 2 |
| 86 | 0 | 1 | 2 |
| 87 | 0 | 1 | 2 |
| 88 | 0 | 1 | 2 |
| 89 | 0 | 1 | 2 |
| 90 | 0 | 1 | 2 |
| 91 | 0 | 1 | 2 |
| 92 | 0 | 1 | 2 |
| 93 | 0 | 1 | 2 |
| 94 | 0 | 1 | 2 |
| 95 | 0 | 1 | 2 |
| 96 | 0 | 1 | 2 |
| 97 | 0 | 1 | 2 |
| 98 | 0 | 1 | 2 |
| 99 | 0 | 1 | 2 |
| 100 | 0 | 1 | 2 |

| | | |
|-----------------|---|---|
| 1 | 8 | 0 |
| 1 | 7 | 5 |
| 1 | 6 | 2 |
| 1 | 5 | 1 |
| 1 | 4 | 2 |
| 1 | 3 | 3 |
| 1 | 2 | 3 |
| 1 | 1 | 3 |
| 1 | 0 | 3 |
| ni ^a | 9 | 0 |
| Volts | 0 | 0 |


This P.C.B. connection diagram is viewed from the foil side.

4.2 ANALOG BOARD ASSEMBLY(PWM 1490)

ANALOG BOARD ASSEMBLY (PWM1490:KU,KC,HEM AND SD TYPES) (PWM1492:HB TYPE)

TO
POWER TRANSFORMER

GRY
ORG
YEL
BRN
RED
BLK



TO MAIN BOARD
ASSEMBLY

TO MAIN BOARD
ASSEMBLY

| P.C.B. pattern diagram indication | Corresponding part symbol | Part name | P.C.B. pattern diagram indication | Corresponding part symbol | Part name |
|-----------------------------------|---------------------------|-------------|-----------------------------------|---------------------------|--|
| | | Transistor | | | Ceramic capacitor |
| | | FET | | | Mylar capacitor |
| | | Diode | | | Styrol capacitor |
| | | Zener diode | | | Electrolytic capacitor (Non polarized) |
| | | LED | | | Electrolytic capacitor (Polarized) |
| | | Varactor | | | Power capacitor |
| | | Tact switch | | | Semi-fixed resistor |
| | | Inductor | | | Resistor array |
| | | Coil | | | Resistor |
| | | Transformer | | | Resonator |
| | | Filter | | | Thermistor |

- This P.C.B. connection diagram is viewed from the parts mounted side.
- The parts which have been mounted on the board can be replaced with those shown with the corresponding wiring symbols listed in the above Table.
- The capacitor terminal marked with shows negative terminal.
- The diode marked with shows cathode side.
- The transistor terminal marked with shows emitter.

IC602
Q554 Q555
IC621 Q563
Q562
Q559 Q560
Q558 Q561

IC554 IC555

IC620
IC601
Q525

Q524
IC522 IC523
Q521

IC501 IC502

IC512
IC513

Q523 Q522

*1


IC522, IC523 (PD2028A)

| Pin No. | Voltage | Pin No. | Voltage |
|---------|---------|---------|---------|
| 1 | 0 | 15 | 5 |
| 2 | 2.6 | 16 | 5 |
| 3 | 2 | 17 | 5 |
| 4 | 0 | 18 | 0 |
| 5 | 5 | 19 | 3.8 |
| 6 | 5 | 20 | 2.2 |
| 7 | 2.3 | 21 | 0 |
| 8 | 2.5 | 22 | 0 |
| 9 | 0 | 23 | 0 |
| 10 | 5 | 24 | 0 |
| 11 | 0 | 25 | 3.2 |
| 12 | 2 | 26 | 2.5 |
| 13 | 2.6 | 27 | 0 |
| 14 | 0 | 28 | 5 |

*2

IC513 (SM5840CP)



| Pin No. | Voltage |
|---------|---------|
| 1 | 5 |
| 2 | 2.5 |
| 3 | 2.6 |
| 4 | 2.4 |
| 5 | 0 |
| 6 | 0 |
| 7 | 0 |
| 8 | 0 |
| 9 | 4 |
| 10 | 3 |
| 11 | 3.6 |
| 12 | 3.2 |
| 13 | 3.6 |
| 14 | 5 |
| 15 | 1.4 |
| 16 | 2.5 |
| 17 | 2.4 |
| 18 | 0 |



4.3 WAVEFORMS

Note: The encircled numbers denote measuring in the schematic diagram.

*1 50T-JUMP: After switching to the pause mode, press the manual search key.
*2 FOCUS-IN: Press the key without loading a disc.



5. P.

NOTES:
• Parts
• Parts
• unava
• The
• There
• When
Ex. 1

Ex. 2

Mark No.

● ANALO

SEMICON

△ IC501
IC512
IC513
IC522
IC554

△ IC601
△ IC602
△ IC620


Q521
Q522,
Q524,
Q554,
Q558

Q559,
Q561
Q562,

D521
D550,
D570,
D610-
D620-]

COILS ANI

L511,I
L522,I
L525,I
L540-I
L551-I
L564



5. P.C.B.'s PARTS LIST

NOTES :

- Parts without part number cannot be supplied.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560Ω 56 × 10¹ 561 RD1/4PS561J

47kΩ 47 × 10³ 473 RD1/4PS473J

0.5Ω 0R5 RD2H0R5K

1Ω 010 RD1P010K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62kΩ 562 × 10¹ 5621 RD1/4SR5621F

| Mark | No. | Description | Parts No. | Mark | No. | Description | Parts No. |
|----------------------------------|-----|------------------------------|-------------|------------|-----|--------------------------------|-------------|
| ●ANALOG BOARD ASSEMBLY (PWM1490) | | | | CAPACITORS | | | |
| SEMICONDUCTORS | | | | | | | |
| Δ | | IC501,IC502 REGULATOR IC | NJM7805FA | | | C501,C502 AUDIO FILM CAPACITOR | CFTXA104J50 |
| | | IC512 LOGIC IC | TC74HCU04AP | | | C503,C504 CERAMIC CAPACITOR | PCL1029 |
| | | IC513 DIGITAL FILTER,IC | SM5840CP | | | C505 ELECTR.CAPACITOR | CEAS101M25 |
| | | IC522,IC523 D/A CONVERTER,IC | PD2028A | | | C506,C507 AUDIO FILM CAPACITOR | CFTXA104J50 |
| | | IC554,IC555 OP-AMP IC | NJM5532DD | | | C511 CERAMIC CAPACITOR | PCL1029 |
| Δ | | IC601 REGULATOR IC | NJM7812FA | | | C512 AUDIO FILM CAPACITOR | CFTXA103J50 |
| Δ | | IC602 REGULATOR IC | NJM7912FA | | | C514 CERAMIC CAPACITOR | CGCYF473Z25 |
| Δ | | IC620,IC621 IC PROTECTOR | ICP-N15 | | | C515 AUDIO FILM CAPACITOR | CFTXA103J50 |
| | | Q521 TRANSISTOR | DTC124ES | | | C516 ELECTR.CAPACITOR | CEAS102M16 |
| | | Q522,Q523 TRANSISTOR | DTA124ES | | | C517,C518 CERAMIC CAPACITOR | CCCCH120J50 |
| | | Q524,Q525 TRANSISTOR | DTC124ES | | | C519 ELECTR.CAPACITOR | CEAS102M16 |
| | | Q554,Q555 TRANSISTOR | 2SC3068 | | | C520 ELECTR.CAPACITOR | CEAS470M50 |
| | | Q558 TRANSISTOR | 2SK246 | | | C521 MYLOR FILM CAPACITOR | CQMA473J50 |
| | | Q559,Q560 FET | 2SJ103 | | | C522 MYLOR FILM CAPACITOR | CQMA104J50 |
| | | Q561 TRANSISTOR | 2SK246 | | | C523 CERAMIC CAPACITOR | PCL1029 |
| | | Q562,Q563 TRANSISTOR | 2SC3068 | | | C524 ELECTR.CAPACITOR | CEAS102M16 |
| | | D521 DIODE | 1SS254 | | | C526 MYLOR FILM CAPACITOR | CQMA104J50 |
| | | D550,D551 DIODE | 1SS254 | | | C528 ELECTR.CAPACITOR | CEAS102M16 |
| | | D570,D571 DIODE | 1SS254 | | | C530,C531 MYLOR FILM CAPACITOR | CQMA104J50 |
| | | D610-D613 DIODE | 10DF2 | | | C532 ELECTR.CAPACITOR | CEAS102M16 |
| | | D620-D627 DIODE | 10DF2 | | | C534 AUDIO FILM CAPACITOR | CFTXA104J50 |
| COILS AND FILTERS | | | | | | C535 ELECTR.CAPACITOR | CEAS102M16 |
| | | L511,L512 AXIAL INDUCTOR | LAU010K | | | C538,C539 CERAMIC CAPACITOR | CCCCH120J50 |
| | | L522,L523 AXIAL INDUCTOR | LAU010K | | | C540,C541 CERAMIC CAPACITOR | CCDCH221J50 |
| | | L525,L526 AXIAL INDUCTOR | LAU010K | | | C542,C543 CERAMIC CAPACITOR | CCCCH181J50 |
| | | L540-L549 FERRITE BEADS | PTH1010 | | | C544,C545 CERAMIC CAPACITOR | CCCCH330J50 |
| | | L551-L554 FERRITE BEADS | VTH1013 | | | C546,C547 CERAMIC CAPACITOR | CGCYF473Z25 |
| | | L564 | PTH1006 | | | C548,C549 CERAMIC CAPACITOR | CCDCH080D50 |
| | | | | | | C550,C551 CERAMIC CAPACITOR | CCCCH181J50 |
| | | | | | | C552,C553 CERAMIC CAPACITOR | CCCCH330J50 |
| | | | | | | C554,C555 MYLOR FILM CAPACITOR | CQMA104J50 |
| | | | | | | C556,C557 ELECTR.CAPACITOR | CEAS102M16 |
| | | | | | | C558,C559 MYLOR FILM CAPACITOR | CQMA104J50 |
| | | | | | | C560-C563 CERAMIC CAPACITOR | CCCCH470J50 |
| | | | | | | C564,C565 MYLOR FILM CAPACITOR | CQMA681J50 |

| Mark | No. | Description | Parts No. | Mark | No. | Description | Parts No. |
|---------------------------------------|-----------------|-----------------------|--------------|--------------------------|------------|----------------------|-------------|
| | C566, C567 | MYLOR FILM CAPACITOR | CQMA562J50 | | Q351 | TRANSISTOR | DTA124ES |
| | C568, C571 | ELECTR. CAPACITOR | CEAS471M50 | | Q391 | TRANSISTOR | DTC124ES |
| | C572, C573 | ELECTROLYTIC CAPACIT | PCH1094 | △ | D11-D14 | DIODE | 11ES2 |
| | C574, C575 | PL. STYRENE CAPACITOR | CQSA102J50 | △ | D25 | | RB-152LF |
| | C576, C577 | ELECTR. CAPACITOR | CEAS102M16 | △ | D51, D52 | DIODE | 11ES2 |
| | C578, C579 | CERAMIC CAPACITOR | PCL1029 | △ | D53 | ZENER DIODE | MTZ27C |
| | C581 | MYLOR FILM CAPACITOR | CQMA104J50 | △ | D54 | ZENER DIODE | MTZJ20A |
| | C584, C585 | CERAMIC CAPACITOR | PCL1029 | △ | D56 | DIODE | 11ES2 |
| | C587, C588 | ELECTR. CAPACITOR | CEANP220M25 | | D391-D399 | DIODE | 1SS254 |
| | C589 | ELECTR. CAPACITOR | CEAS102M16 | | | | |
| | C590, C591 | MYLOR FILM CAPACITOR | CQMA104J50 | | | | |
| | C593, C594 | ELECTR. CAPACITOR | CEAS102M16 | | | | |
| | C595 | MYLOR FILM CAPACITOR | CQMA104J50 | | | | |
| | C597 | ELECTR. CAPACITOR | CEAS102M16 | | | | |
| | C601 | ELECTROLYTIC CAPACIT | CENA102M35 | | | | |
| | C604, C605 | ELECTR. CAPACITOR | PCH1102 | | | | |
| | C606, C607 | ELECTROLYTIC CAPACIT | CENA102M35 | | | | |
| | C608-C618 | CERAMIC CAPACITOR | PCL1029 | | | | |
| RESISTORS | | | | COILS AND FILTERS | | | |
| | R540-R567 | CARBON FILM RESISTOR | RD1/4PM□□□J | | L30 | AXIAL INDUCTOR | LAU010K |
| | R576-R581 | CARBON FILM RESISTOR | RDR1/4PM□□□J | | L301 | RADIAL INDUCTOR | LRA010K |
| | R582-R585 | CARBON FILM RESISTOR | RDR1/2PM□□□J | | L332 | COIL | PTL1003 |
| | R588, R589 | CARBON FILM RESISTOR | RDR1/2PM271J | | L391, L392 | AXIAL COIL | LAUR22K |
| | R590, R591 | CARBON FILM RESISTOR | RDR1/4PM511J | | L393 | AXIAL INDUCTOR | LAU010K |
| | R593, R594 | CARBON FILM RESISTOR | RDR1/4PM331J | | | | |
| | Other resistors | | RD1/6PM□□□J | | | | |
| OTHERS | | | | CAPACITORS | | | |
| | CN501 | CONNECTOR(10P) | KPC10 | | C10, C11 | CERAMIC CAPACITOR | PCL1029 |
| | JA551 | 1P PIN JACK(W) | RKB1010 | | C13-C20 | CERAMIC CAPACITOR | PCL1029 |
| | JA552 | 1P PIN JACK(R) | RKB1011 | | C21, C22 | ELECTR. CAPACITOR | CEAS222M25 |
| | X512 | XTAL RES (OSC) | PSS1011 | | C23 | ELECTR. CAPACITOR | CEAS102M25 |
| | SCREW | | BBZ30P080FCC | | C25, C26 | ELECTR. CAPACITOR | CEAS222M16 |
| ●MAIN BOARD ASSEMBLY (PWZ2150) | | | | | C27, C28 | ELECTR. CAPACITOR | CEAS222M25 |
| SEMICONDUCTORS | | | | | C29, C30 | ELECTR. CAPACITOR | CEAS102M16 |
| △ | IC11 | REGULATOR IC | NJM7805FA | | C51 | ELECTR. CAPACITOR | CEAS101M50 |
| | IC12 | REGULATOR IC | NJM7905FA | | C52 | ELECTR. CAPACITOR | CEAS221M50 |
| △ | IC13 | REGULATOR IC | NJM7808FA | | C53 | ELECTR. CAPACITOR | CEAS100M50 |
| △ | IC14 | REGULATOR IC | NJM7908FA | | C54 | ELECTR. CAPACITOR | CEAS470M50 |
| △ | IC30-IC32 | IC PROTECTOR | ICP-N10 | | C55 | ELECTROLYTIC CAPACIT | CEAS330M35 |
| | IC60 | SYSTEM RESET IC | M51957AL | | C56 | ELECTR. CAPACITOR | CEAS101M50 |
| | IC101 | PRE AMP IC | CXA1471S | | C61 | ELECTR. CAPACITOR | CEASR33M50 |
| | IC151 | SERVO IC | CXA1372S | | C62 | ELECTR. CAPACITOR | CEAS010M50 |
| △ | IC201 | POWER OP-AMP, IC | LA6520 | | C101, C102 | ELECTR. CAPACITOR | CEAS221M25 |
| △ | IC202 | POWER OP-AMP, IC | LA6517 | | C103 | CERAMIC CAPACITOR | CCCCH200J50 |
| | IC301 | EFM DEMODULATION IC | CXD2500AQ | | C104 | ELECTR. CAPACITOR | CEAS101M10 |
| | IC331 | IC | MC74HCU04N | | C105, C106 | ELECTR. CAPACITOR | CEAS221M25 |
| | Q51 | TRANSISTOR | 2SB1187 | | C107, C108 | CERAMIC CAPACITOR | CGCYX103K25 |
| | Q101 | TRANSISTOR | 2SA854S | | C110 | CERAMIC CAPACITOR | CKCYF103Z50 |
| | Q240 | TRANSISTOR | 2SA933S | | C151-C154 | ELECTR. CAPACITOR | CEAS221M25 |
| | Q241 | TRANSISTOR | 2SC1740S | | C155 | CERAMIC CAPACITOR | CKCYB182K50 |
| | Q331 | TRANSISTOR | DTC124ES | | C156 | CERAMIC CAPACITOR | CGCYX333K25 |
| | | | | | C157 | CERAMIC CAPACITOR | CGCYX103K25 |
| | | | | | C158, C159 | MYLOR FILM CAPACITOR | CQMA104K50 |
| | | | | | C160 | ELECTR. CAPACITOR | CEAS4R7M50 |
| | | | | | C161 | MYLOR FILM CAPACITOR | CQMA104K50 |
| | | | | | C162 | ELECTR. CAPACITOR | CEAS010M50 |
| | | | | | C163 | MYLOR FILM CAPACITOR | CQMA104K50 |
| | | | | | C164 | CERAMIC CAPACITOR | CGCYX103K25 |
| | | | | | C166 | CERAMIC CAPACITOR | CCCSL101J50 |
| | | | | | C167 | CERAMIC CAPACITOR | CKCYF103Z50 |
| | | | | | C168 | CERAMIC CAPACITOR | CGCYX333K25 |
| | | | | | C169 | CERAMIC CAPACITOR | CGCYX103K25 |

| Mark | No. | Description | Parts No. |
|------|-----------|----------------------|-------------|
| | C170 | CERAMIC CAPACITOR | CKCYB332K50 |
| | C171,C172 | CERAMIC CAPACITOR | CKCYB472K50 |
| | C202 | CERAMIC CAPACITOR | CKCYF103Z50 |
| | C212 | CERAMIC CAPACITOR | CKCYB272K50 |
| | C216-C219 | ELECTR. CAPACITOR | CEAS221M25 |
| | C232 | CERAMIC CAPACITOR | CKCYF103Z50 |
| | C301 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C302,C303 | ELECTR. CAPACITOR | CEAS471M10 |
| | C304 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C305 | ELECTR. CAPACITOR | CEAS471M10 |
| | C306 | CERAMIC CAPACITOR | CKCYB152K50 |
| | C307 | CERAMIC CAPACITOR | CGCYX473K25 |
| | C308 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C309 | ELECTR. CAPACITOR | CEAS47M50 |
| | C310 | CERAMIC CAPACITOR | CKCYF103Z50 |
| | C311 | CERAMIC CAPACITOR | CKCYB102K50 |
| | C313 | CERAMIC CAPACITOR | CKCYF103Z50 |
| | C331 | CERAMIC CAPACITOR | CGCYX473K25 |
| | C332 | ELECTR. CAPACITOR | CEAS101M25 |
| | C334 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C335 | ELECTR. CAPACITOR | CEAS470M25 |
| | C336 | AUDIO FILM CAPACITOR | CFTXA103J50 |
| | C337 | CERAMIC CAPACITOR | CCCSL471J50 |
| | C339,C340 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C391 | CERAMIC CAPACITOR | CGCYX103K25 |
| | C392 | CERAMIC CAPACITOR | CCCSL101J50 |
| | C395 | CERAMIC CAPACITOR | CCDSL100D50 |

RESISTORS

| | | |
|-----------------|----|-------------|
| VR102 | VR | VRTB6VS223 |
| VR103 | VR | VRTB6VS102 |
| VR151 | VR | VRTB6VS223 |
| VR152 | VR | VRTB6VS223 |
| Other resistors | | RD1/6PM□□□J |

OTHERS

| | | |
|-------------|---------------------|------------|
| CN101 | CONNECTOR | 52045-1610 |
| CN351 | CONNECTOR | HLEM33S |
| JA331 | OPTICAL OUTPUT JACK | TOTX178 |
| JA332 | JACK | PKB1004 |
| JA391,JA392 | JACK | RKN1004 |
| JA393 | JACK | RKN1014 |

PRIMARY BOARD ASSEMBLY**SWITCHES**

| | | |
|---|-------------------|---------|
| △ | S1 SWITCH (POWER) | PSA-009 |
|---|-------------------|---------|

CAPACITORS

| | | |
|---|------------------------|---------|
| △ | C1 CAPACITOR (CERAMIC) | VCG-048 |
|---|------------------------|---------|

| Mark | No. | Description | Parts No. |
|------|-----|-------------|-----------|
|------|-----|-------------|-----------|

●FUNCTION A BOARD ASSEMBLY (PWZ2168)

SEMICONDUCTORS

| | | |
|-----------|------------------|----------|
| IC401 | MICROCOMPUTER,IC | PD4329A |
| Q402,Q403 | TRANSISTOR | DTC124ES |
| Q404,Q405 | TRANSISTOR | DTA124ES |
| D401 | LED | AA0045 |
| D402 | LED | BR0045 |
| D411-D416 | DIODE | 1SS254 |

SWITCHES

| | | |
|---------------------------|--------|---------|
| S401-S406 | SWITCH | PSG-065 |
| (TRK FF, TRK REV, PAUSE) | | |
| (PLAY, OPEN/CLOSE, STOP) | | |

FILTERS

| | | |
|-----------|----------------|---------|
| L401,L402 | AXIAL INDUCTOR | LAU010K |
|-----------|----------------|---------|

CAPACITORS

| | | |
|-----------|----------------------|--------------|
| C401,C402 | ELECTROLYTIC CAPACIT | CEJA470M16 |
| C403 | CERAMIC CAPACITOR | CKPUYF103Z25 |
| C404 | ELECTROLYTIC CAPACIT | CEJA470M16 |
| C405 | CERAMIC CAPACITOR | CKPUYF103Z25 |
| C406-C408 | CERAMIC CAPACITOR | CGCYX103K25 |
| C409 | CERAMIC CAPACITOR | CKCYF103Z50 |
| C411-C416 | AXIAL CERAMIC C. | CCPUCH100J50 |

RESISTORS

| | |
|---------------|-------------|
| All resistors | RD1/6PM□□□J |
|---------------|-------------|

OTHERS

| | | |
|-------|-------------------|---------|
| CN401 | CONNECTOR | HLEM33R |
| V401 | FL TUBE | PEL1025 |
| X401 | CERAMIC RESONATOR | VSS1014 |
| | REMOTE SENSOR | SBX1610 |

FUNCTION B BOARD ASSEMBLY**SEMICONDUCTORS**

| | | |
|------|-------|-------------|
| D403 | LED | SLH-34YC3H3 |
| D404 | LED | SLH-34VC3H3 |
| D405 | LED | SLH-34VC3H3 |
| D417 | DIODE | 1SS254 |

SWITCHES

| | | |
|-----------------------|--------|---------|
| S407,S408 | SWITCH | PSG-065 |
| (DISPLAY OFF, OUTPUT) | | |

CAPACITORS

| | | |
|------|------------------|--------------|
| C417 | AXIAL CERAMIC C. | CCPUCH100J50 |
|------|------------------|--------------|

6. ADJUSTMENTS

If a disc player is adjusted incorrectly or inadequately, it may malfunction or not work at all even though there is nothing at all wrong with the pick up or the circuitry. Adjust correctly following the adjustment procedure.

6-1. Adjustment items/verification item and order

| Step | Item | Test point | Adjustment location |
|------|---|---|---|
| 1 | Focus offset adjustment | TP 1, Pin 6(FCS.ERR) | VR 103(FCS.OFS) |
| 2 | Grating adjustment | TP 1, Pin 2(TRK.ERR) | Grating adjustment slit |
| 3 | Tracking error balance adjustment | TP 1, Pin 2(TRK.ERR) | VR 102(TRK. BAL) |
| 4 | Pick up radial/tangential direction tilt adjustment | TP 1, Pin 1(RF) | Radial tilt adjustment screw, Tangential tilt adjustment screw |
| 5 | RF level adjustment (RF level) | TP 1, Pin 1(RF) | VR 1(RF level) |
| 6 | Focus servo loop gain adjustment | TP 1, Pin 5(FCS.IN) TP 1, Pin 6(FCS.ERR) | VR 152(FCS.GAN) |
| 7 | Tracking servo loop gain adjustment | TP 1, Pin 3(TRK.IN) TP 1, Pin 2(TRK.ERR) | VR 151(TRK.GAN) |
| 8 | Focus error signal verification | TP 1, Pin 6(FCS.ERR) | — |

● Abbreviation table

FCS.ERR : Focus Error
 FCS.OFS : Focus Offset
 TRK.ERR : Tracking Error
 TRK.BAL : Tracking Balance
 FCS.GAN : Focus Gain
 TRK.GAN : Tracking Gain
 FCS.IN : Focus In
 TRK.IN : Tracking In

6-2. Measuring instruments and tools

1. Dual trace oscilloscope (10 : 1 probe)
2. Low-frequency oscillator
3. Test disc (YEDS-7)
4. Low-pass filter (39 k Ω + 0.001 μ F)
5. Resistor (100 k Ω)
6. Standard tools

6-3. Test point and adjustment variable resistor positions




Figure 1 Adjustment Locations

6-4. Notes

1. Use a 10 : 1 probe for the oscilloscope.
2. All the knob positions (settings) for the oscilloscope in the adjustment procedures are for when a 10 : 1 probe is used.

6-5. Test mode

These models have a test mode so that the adjustments and checks required for service can be carried out easily. When these models are in test mode, the keys on the front panel work differently from normal. Adjustments and checks can be carried out by operating these keys with the correct procedure. For these models, all adjustments are carried out in test mode.

[Setting these models to test mode]

How to set this model into test mode.

1. Turn off the power switch.
2. Short the test mode jumper wires. (See Figure 1.)
3. Turn on the power switch.

When the test mode is set correctly, the display is different from what it usually is when the power is turned on. If the display is still the same as usual, test mode has not been set correctly, so repeat steps 1-3.

[Release from test mode]

Here is the procedure for releasing test mode :

1. Press the STOP key to stop all operations.
2. Turn off the power switch on the front panel.

[Operations of the keys in test mode]


| Code | Key name | Function in test mode | Explanation |
|------|----------|---------------------------|---|
| | OUTPUT | Focus servo close | <p>The laser diode is lit up and the focus actuator is lifted up, then lowered slowly and the focus servo is closed at the point where the objective lens is focused on the disc. With the player in this state, if you lightly rotate the stopped disc by hand, you can hear the sound the focus servo.</p> <p>If you can hear this sound, the focus servo is operating correctly. If you press this key with no disc mounted, the laser diode lights up, the focus actuator is pulled up, then the actuator is lowered and raised twice and returned to its original position.</p> |
| ▷ | PLAY | Spindle servo On | <p>Starts the spindle motor in the clockwise direction and when the disc rotation reaches the prescribed speed (about 500 rpm at the inner periphery), sets the spindle servo in a closed loop.</p> <p>Be careful. Pressing this key when there is no disc mounted makes the spindle motor run at the maximum speed.</p> <p>If the focus servo does not go correctly into a closed loop or the laser light shines on the mirror section at the periphery edge of the disc, the same symptom is occurred.</p> |
| ⏸ | PAUSE | Tracking servo close/open | <p>Pressing this key when the focus servo and spindle servo are operating correctly in closed loops puts the tracking servo into a closed loop, displays the track number being played back and the elapsed time on the front panel, and outputs the playback signal.</p> <p>If the elapsed time is not displayed or not counted correctly or the audio is not played back correctly, it may be that the laser is shining on the section with no sound recorded at the outer edge of the disc, that something is out of adjustment, or that there is some other problem.</p> <p>This key is a toggle key and open/close the tracking servo alternately. This key has no effect if no disc is mounted.</p> |

| Code | Key name | Function in test mode | Explanation |
|------|------------|--------------------------------|--|
| ⏮ | TRACK REV | Carriage reverse (inwards) | Moves the pickup position toward the inner diameter of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the pickup does not automatically stop at the mechanical end point in test mode, be careful with this operation. |
| ⏭ | TRACK FWD | Carriage forward (outwards) | Moves the pickup position toward the outer diameter of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the pickup does not automatically stop at the mechanical end point in test mode, be careful with this operation. |
| □ | STOP | Stop | Initializes and the disc rotation stops. The pickup and disc remain where they are when this key is pressed. |
| △ | OPEN/CLOSE | Disc tray open/close | Opens/closes the disc tray. This key is a toggle key and open/close tray alternately. |

[How to play back a disc in test mode]

In test mode, since the servos operate independently, playing back a disc requires that you operate the keys in the correct order to close the servos.

Here is the key operation sequence for playing back a disc in test mode.



Wait at least 2-3 seconds between each of these operations.

1. Focus offset adjustment

| | | | |
|--------------------------------------|--|-----------------------|---|
| ● Objective | Sets the DC offset for the focus error amp. | | |
| ● Symptom when out of adjustment | The model does not focus in and the RF signal is dirty. | | |
| ● Measurement instrument connections | Connect the oscilloscope to TP 1, Pin 6 (FCS ERR). | ● Player state | Test mode, stopped (just the Power switch on) |
| | [Settings] 5 mV/division 10 ms/division DC mode | ● Adjustment location | VR 103 (FCS OFS) |
| | | ● Disc | None needed |

[Procedure]

Adjust VR 103 (FCS OFS) so that the DC voltage at TP 1, Pin 6 (FCS ERR) is -150 ± 50 mV.

2. Grating adjustment

| | | | |
|--------------------------------------|--|-----------------------|---|
| ● Objective | To align the tracking error generation laser beam spots to the optimum angle on the track. | | |
| ● Symptom when out of adjustment | Play does not start, track search is impossible, tracks are skipped. | | |
| ● Measurement instrument connections | Connect the oscilloscope to TP 1, Pin 2 (TRK ERR) via a low pass filter. (See Figure 2) | ● Player state | Test mode, focus and spindle servos closed and tracking servo open. |
| | [Settings] 50 mV/division 5 ms/division DC mode | ● Adjustment location | Pickup grating adjustment slit |
| | | ● Disc | YEDS-7 |

[Procedure]

1. Move the pickup to midway across the disc (R=35 mm) with the TRACK FWD \blacktriangleright or REV \blacktriangleleft key.
2. Press the OUTPUT key, then the PLAY \blacktriangleright key in that order to close the focus servo then the spindle servo.
3. Insert an ordinary screwdriver into the grating adjustment slit and adjust the grating to find the null point. For more details, see the next page.
4. If you slowly turn the screwdriver clockwise from the null point, the amplitude of the wave gradually increases, then if you continue turning the screwdriver, the amplitude of the wave becomes smaller again. Turn the screwdriver clockwise from the null point and set the grating to the first point where the wave amplitude reaches its maximum.

Reference : Figure 3 shows the relation between the angle of the tracking beam with the track and the waveform.

Note : The amplitude of the tracking error signal is about 3 V_{p-p} (when a 39 k Ω + 0.001 μ F low pass filter is used). If this amplitude is extremely small (2 V_{p-p} or less), then the objective lens or the pickup malfunction may be the cause. If the difference between the amplitude of the error signal at the innermost edge and outermost edge of the disc is more than 10%, the grating is not adjusted to the optimum point, so adjust it again.

5. Return the pickup to more or less midway across the disc with the TRACK REV \blacktriangleleft key, press the PAUSE \square key and double check that the track number and elapsed time are displayed on the front panel. If they are not displayed at this time or the elapsed time changes irregularly, double check the null point and adjust the grating again.





Figure 2



[How to find the null point]

When you insert the regular screwdriver into the slit for the grating adjustment and change the grating angle, the amplitude of the tracking error signal at TP 1 Pin 2 changes. Within the range for the grating, there are five or six locations where the amplitude of the wave reaches a minimum. Of these five or six locations, there is only one at which wave form is smooth. This location is where the three laser beams divided by the grating are all right above the same track. (See Figure 3.)

This point is called the null point. When adjusting the grating, this null point is found and used as the reference position.





Figure 3




3. Tracking error balance adjustment

| | | | |
|--------------------------------------|--|-----------------------|--|
| ● Objective | To correct for the variation in the sensitivity of the tracking photodiode. | | |
| ● Symptom when out of adjustment | Play does not start or track search is impossible. | | |
| ● Measurement instrument connections | Connect the oscilloscope to TP 1, Pin 2 (TRK ERR). This connection may be via a low pass filter. | ● Player state | Test mode, focus and spindle servos closed and tracking servo open |
| | [Settings] 50 mV/division 5 ms/division DC mode | ● Adjustment location | VR 102 (TRK BAL) |
| | | ● Disc | YEDS-7 |

[Procedure]

1. Move the pickup to midway across the disc ($R = 35 \text{ mm}$) with the TRACK FWD $\blacktriangleright\blacktriangleright$ or REV $\blacktriangleleft\blacktriangleleft$ key.
2. Press the OUTPUT key, then the PLAY key in that order to close the focus servo then the spindle servo.
3. Line up the bright line (ground) at the center of the oscilloscope screen and put the oscilloscope into DC mode.
4. Adjust VR 102 (TRK BAL) so that the positive amplitude and negative amplitude of the tracking error signal at TP 1 Pin 2 (TRK ERR) are the same (in other words, so that there is no DC component).



4. Pickup radial/tangential tilt adjustment

| | | | |
|--------------------------------------|---|-----------------------|--|
| ● Objective | To adjust the angle of the pickup relative to the disc so that the laser beams are shone straight down into the disc for the best read out of the RF signals. | | |
| ● Symptom when out of adjustment | Sound broken ; some discs can be played but not others. | | |
| ● Measurement instrument connections | Connect the oscilloscope to TP 1, Pin 1 (RF). | ● Player state | Test mode, play |
| | [Settings] 20 mV/division 200 ns/division AC mode | ● Adjustment location | Pickup radial tilt adjustment screw and tangential tilt adjustment screw |
| | | ● Disc | YEDS-7 |

[Procedure]

1. Press the TRACK FWD or REV key to move the pickup to halfway across the disc ($R = 35$ mm). Press the OUTPUT key, the PLAY key, then the PAUSE key in that order to close the focus servo then the spindle servo and put the player into play mode.
2. First, adjust the radial tilt adjustment screw with a Phillips screwdriver so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly.
3. Next, adjust the tangential tilt adjustment screw with a Phillips screwdriver so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly (Figure 5).
4. Adjust the radial tilt adjustment screw and the tangential tilt adjustment screw again so that the eye pattern can be seen the most clearly. As necessary, adjust the two screws alternately so that the eye pattern can be seen the most clearly.

Note : Radial and tangential mean the directions relative to the disc shown in Figure 4.




Figure 4




Figure 5 Eye pattern

5. RF level adjustment

| | | | |
|--------------------------------------|---|-----------------------|--------------------|
| ● Objective | To optimize the playback RF signal amplitude | | |
| ● Symptom when out of adjustment | No play or no search | | |
| ● Measurement instrument connections | Connect the oscilloscope to TP 1, Pin 1 (RF). | ● Player state | Test mode, play |
| | [Settings] 50 mV/division 10 ms/division AC mode | ● Adjustment location | VR 1 (laser power) |
| | | ● Disc | YEDS-7 |

[Procedure]

1. Move the pickup to midway across the disc ($R = 35 \text{ mm}$) with the TRACK FWD \blacktriangleright or REV \blacktriangleleft key, then press the OUTPUT key, then the PLAY \blacktriangleright key in that order to close the respective servos and put the player into play mode..
2. Adjust VR 1 (laser power) so that the RF signal amplitude is $1.2 \text{ V}_{p-p} \pm 0.1 \text{ V}$.

6. Focus servo loop gain adjustment

| | | | |
|--------------------------------------|--|-----------------------|------------------|
| ● Objective | To optimize the focus servo loop gain | | |
| ● Symptom when out of adjustment | Playback does not start or focus actuator noisy | | |
| ● Measurement instrument connections | See Figure 6. | ● Player state | Test mode, play |
| | <div>[Settings]</div> <div>CH 1 CH 2</div> <div>20 mV/division 5 mV/division</div> <div>X-Y mode</div> | ● Adjustment location | VR 152 (FCS GAN) |
| | | ● Disc | YEDS-7 |

[Procedure]

1. Set the AF generator output to 1.2 kHz and 1 Vp-p.
2. Press the TRACK FWD or REV key to move the pickup to halfway across the disc (R = 35 mm), then press the OUTPUT key, the PLAY key, then the PAUSE key in that order to close the corresponding servos and put the player into play mode.
3. Adjust VR 152 (FCS GAN) so that the Lissajous wave form is symmetrical about the X axis and the Y axis.





Figure 6


Focus Gain Adjustment



Higher gain



Optimum gain







Lower gain

7. Tracking servo loop gain adjustment

| | | | |
|--------------------------------------|--|-----------------------|------------------|
| ● Objective | To optimize the tracking servo loop gain | | |
| ● Symptom when out of adjustment | Playback does not start, during searches the actuator is noisy, or tracks are skipped. | | |
| ● Measurement instrument connections | See Figure 7. | ● Player state | Test mode, play |
| | [Settings] CH 1 50 mV/division X-Y mode | ● Adjustment location | VR 151 (TRK GAN) |
| | CH 2 50 mV/division X-Y mode | ● Disc | YEDS-7 |

[Procedure]

1. Set the AF generator output to 1.2 kHz and 1 V_{p-p}.
2. Press the TRACK FWD  or REV  key to move the pickup to halfway across the disc (R = 35 mm), then press the OUTPUT key, the PLAY  key, then the PAUSE  key in that order to close the corresponding servos and put the player into play mode.
3. Adjust VR 151 (TRK GAN) so that the Lissajous wave form is symmetrical about the X axis and the Y axis.






Figure 7

Tracking Gain Adjustment



Higher gain



Optimum gain



Lower gain

8. Focus error signal(focus S curve)verification

| | | | |
|--------------------------------------|--|-----------------------|-----------------|
| ● Objective | To judge whether the pickup is O.K. or not by observing the focus error signal. The pickup is judged from the amplitude of the tracking error signal (as discussed in the section on adjusting the tracking error balance) and the wave form for the focus error signal. | | |
| ● Symptom when out of adjustment | | | |
| ● Measurement instrument connections | Connect the oscilloscope to TP 1 Pin 6 (FOCS ERR). | ● Player state | Test mode, stop |
| | [Settings] 100 mV/division 5 ms/division DC mode | ● Adjustment location | None |
| | | ● Disc | YEDS-7 |

[Procedure]

1. Connect TP 1 Pin 5 to ground.
2. Mount the disc.
3. While watching the oscilloscope screen, press the OUTPUT key and observe the waveform in Figure 8 for a moment. Verify that the amplitude is at least 2.5 V_{p-p} and that the positive and negative amplitude are about equal. Since the waveform is only output for a moment when the OUTPUT key is pressed, press this key over and over until you have checked the waveform.




Figure 8

[Judging the pickup]

Do not judge the pickup until all the adjustments have been made correctly. In the following cases, there may be something wrong with the pickup.

1. The tracking error signal amplitude is extremely small (less than 2 V_{p-p}).
2. The focus error signal amplitude is extremely small (less than 2.5 V_{p-p}).
3. The positive and negative amplitudes of the focus error signal are extremely asymmetrical (2 : 1 ratio or more).
4. The RF signal is too small (less than 0.8 V_{p-p}) and even if VR 1 is adjusted (laser power), the RF signal can not be brought up to the standard level.

6. RÉGLAGE

Si le lecteur CD est mal réglé, il risque de ne plus fonctionner normalement, voire ne plus fonctionner du tout, même si le capteur et la circuiterie en présentent aucune anomalie. Par conséquent, ajuster le lecteur correctement en suivant les démarches de réglage.

6-1. Points de réglage/Point et ordre de vérification

| Etape | Point | Point d'essai | Emplacement du réglage |
|-------|--|---|---|
| 1 | Réglage du décalage de la mise au point | TP1, Broche 6 (FCS.ERR) | VR103 (FCS.OFS) |
| 2 | Réglage du réseau de diffraction | TP1, Broche 2 (TRK.ERR) | Fente de réglage du réseau de diffraction |
| 3 | Réglage d'équilibrage d'erreur d'alignement | TP1, Broche 2 (TRK.ERR) | VR102 (TRK.BAL) |
| 4 | Réglage d'inclinaison radiale/tangentielle du capteur | TP1, Broche 1 (RF) | Vis de réglage d'inclinaison radiale, Vis de réglage d'inclinaison tangentielle |
| 5 | Réglage du niveau RF | TP1, Broche 1 (RF) | VR1 (niveau RF) |
| 6 | Réglage de gain de boucle asservie de la mise au point | TP1, Broche 5 (FCS.IN) TP1, Broche 6 (FCS.ERR) | VR152 (FCS.GAN) |
| 7 | Réglage de gain de boucle asservie de l'alignement | TP1, Broche 3 (TRK.IN) TP1, Broche 2 (TRK.ERR) | VR151 (TRK.GAN) |
| 8 | Vérification du signal d'erreur de la mise au point | TP1, Broche 6 (FCS.ERR) | — |

● Tableau des abréviations

FCS.ERR : erreur de mise au point
 FCS.OFS : décalage de mise au point
 TRK.ERR : erreur d'alignement
 TRK.BAL : équilibrage d'erreur d'alignement
 FCS.GAN : gain de mise au point
 TRK.GAN : gain d'alignement
 FCS.IN : mise au point correcte
 TRK.IN : alignement correct

6-2. Instruments de mesure et outils

1. Oscilloscope cathodique à deux faisceaux (sonde 10 : 1)
2. Oscillateur de basse fréquence
3. Disque d'essai (YEDS-7)
4. Filtre passe-bas ($39k\Omega + 0,001\mu F$)
5. Résistance ($100k\Omega$)
6. Outils conventionnels

6-3. Point d'essai et positions de réglage de la résistance variable




Figure 1 Emplacement des réglages

6-4. Remarques

1. Utiliser une sonde 10 : 1 pour l'oscilloscope.
2. Toutes les positions (réglages) des boutons de l'oscilloscope, dans les démarches de réglage, sont conçues pour l'usage d'une sonde 10 : 1.

6-5. Mode d'essai

Ces modèles sont munis d'un mode d'essai, de façon que les réglages requis à la réparation puissent être effectués aisément. Quand ces modèles sont en mode d'essai, les touches du panneau avant ne fonctionnent pas comme à l'ordinaire.

Les réglages et les vérifications peuvent s'effectuer par l'enclenchement de ces touches, à conditions de suivre les démarches requises. Dans le cas de ces modèles, tous les réglages sont réalisés en mode d'essai.

[Mise en mode d'essai]

Voici la manière de mettre le modèle en mode d'essai.

1. Commuter l'interrupteur d'alimentation sur arrêt.
2. Court-circuiter les fils de liaison du mode d'essai. (voir Figure 1).
3. Commuter l'interrupteur d'alimentation sur marche.

Quand le mode d'essai est correctement réglé, l'affichage est différent de celui qui apparaît généralement à la mise sous tension. Si l'affichage reste le même, le mode d'essai n'a pas été réglé correctement. Dans ce cas, répéter les étapes 1 à 3.

[Pour sortir du mode d'essai]

Voici la procédure qui termine le mode d'essai.

1. Appuyer sur la touche STOP pour arrêter toutes les opérations.
2. Sur le panneau avant, commuter l'interrupteur d'alimentation sur arrêt.

[Fonctionnement des touches en mode d'essai]

| Code | Nom de la touche | Fonction en mode d'essai | Explications |
|------|------------------|--|---|
| | OUTPUT | Fermeture du circuit asservi de la mise au point | <p>La diode laser s'allume et l'actuateur de la mise au point se relève, puis s'abaisse lentement. et le circuit servo de la mise au point se ferme au point où la lentille de l'objectif se focalise sur le disque.</p> <p>Quand l'appareil est dans cet état, si l'on fait légèrement tourner à la main le disque arrêté, le bruit produit par le circuit servo de la mise au point sera audible.</p> <p>Si ce bruit est perçu, le circuit servo de la mise au point fonctionne correctement. Si cette touche est enclenchée et qu'aucun disque n'est installé, la diode laser s'allume, l'actuateur de la mise au point se soulève, se relève, puis s'abaisse et se soulève, une deuxième fois et enfin, revient à sa position départ.</p> |
| ▷ | PLAY | Asservissement de rotation en service | <p>Démarré le moteur de rotation dans le sens des aiguilles d'une montre, quand la rotation du disque atteint la vitesse prescrite (environ 500 tours/min à la circonférence interne) et place le circuit servo de rotation dans une boucle fermée.</p> <p>Attention. Si cette touche est enfoncée et qu'un disque n'est pas installé, le moteur de rotation va tourner à la vitesse maximum.</p> <p>Si le circuit servo de la mise au point ne passe pas comme prévu dans une boucle fermée ou que la diode laser brille dans le miroir à la périphérie externe du disque, le même symptôme se produit.</p> |
| ⏸ | PAUSE | Ouverture/Fermeture du circuit servo de l'alignement | <p>Le fait d'appuyer sur cette touche quand le circuit servo de la mise au point et de la rotation fonctionnent correctement en boucles fermées, place le circuit servo de l'alignement dans une boucle fermée, fait apparaître, sur le panneau avant, le numéro de la piste en cours de lecture et la durée écoulée, puis sort le signal de lecture.</p> <p>Si la durée écoulée n'est pas affichée ou n'est pas correctement calculée, ou si la reproduction sonore est anormale, il se peut que la diode laser s'active dans la section dépourvue de signaux enregistrés, au bord externe du disque, qu'un ajustement quelconque soit dérégulé, ou qu'un autre problème se manifeste.</p> <p>Cette touche est de type à bascule et ouvre/ferme alternativement le circuit servo de l'alignement. Cette touche est inopérante si un disque n'est pas installé.</p> |

| Code | Nom de la touche | Fonction en mode d'essai | Explications |
|------|------------------|---|---|
| ⏮ | TRACK REV | Inversion du chariot (vers l'intérieur) | Déplace le capteur vers la périphérie interne du disque. Quand cette touche est enclenchée et que le circuit servo de l'alignement travaille en bouche fermée, celui-ci change automatiquement dans une boucle ouverte. Comme le capteur ne s'arrête pas automatiquement au point de fin mécanique du mode d'essai, effectuer cette démarche avec précaution. |
| ⏭ | TRACK FWD | Inversion du chariot (vers l'extérieur) | Déplace le capteur vers la périphérie externe du disque. Quand cette touche est enclenchée et que le circuit servo de l'alignement travaille en bouche fermée, celui-ci change automatiquement dans une boucle ouverte. Comme le capteur ne s'arrête pas automatiquement au point de fin mécanique du mode d'essai, effectuer cette démarche avec précaution. |
| □ | STOP | Arrêt | Initialiser et la rotation du disque s'arrête. Le capteur et le disque ne bougent pas lorsque cette touche est enclenchée. |
| △ | OPEN/CLOSE | Ouverture/Fermeture du plateau à disque | Cette touche est de type à bascule et ouvre/ferme alternativement le plateau. Le fait d'enfoncer cette touche quand le plateau est ouvert le ferme et vice versa. |

[Lecture de disque en mode d'essai]

En mode d'essai, comme les circuits servo fonctionnent de manière indépendante, la lecture d'un disque exige que les touches soient enclenchées dans l'ordre prescrit, afin de fermer les circuits servo.

Voici l'ordre d'enclenchement des touches pour reproduire un disque en mode d'essai.

OUTPUT

Allume la diode laser et ferme le circuit servo de la mise au point.



PLAY ▷

Démarre le moteur de rotation et ferme le circuit servo de la rotation.



PAUSE ||

Ferme le circuit servo de l'alignement.

Attendre 2 à 3 secondes entre chaque opération.

1. Réglage du décalage de la mise au point

| | | | |
|--|--|--------------------------|---|
| • Objectif | Règle le décalage CC de l'amplificateur d'erreur de mise au point. | | |
| • Symptôme quand déréglé | Le lecteur ne procède plus à la mise au point et le signal RF n'est pas clair. | | |
| • Raccordement des instruments de mesure | Raccorder l'oscilloscope à TP1, broche 6 (FCS ERR). | • Etat du lecteur | Mode d'essai, arrêté (juste l'interrupteur d'alimentation commuté sur marche) |
| | [Réglages] 5 mV/division 10 ms/division mode CC | • Emplacement du réglage | VR103 (FCS OFS) |
| | | • Disque | Aucun requis |

[Marche à suivre]

Ajuster VR103 (FCS OFS) de façon que la tension à TP1 broche 6(FCS ERR) soit -150 ± 50 mV.

2. Réglage du réseau de diffraction

| | | | |
|--|---|--------------------------|---|
| • Objectif | Pour aligner les points du rayon laser producteur d'erreur d'alignement sur l'angle optimum de la piste | | |
| • Symptôme quand déréglé | La lecture ne commence pas, la recherche de piste est impossible, les pistes sont sautées. | | |
| • Raccordement des instruments de mesure | Raccorder l'oscilloscope à TP1, broche 2 (TRK ERR) via un filtre passe-bas. (Voir Figure 2) | • Etat du lecteur | Mode d'essai, circuits servo de la mise au point et de la rotation fermés, circuit servo de l'alignement ouvert |
| | [Réglages] 50 mV/division 5 ms/division mode CC | • Emplacement du réglage | Fente de réglage du réseau de diffraction du capteur |
| | | • Disque | YEDS-7 |

[Marche à suivre]

1. Déplacer le capteur à mi-chemin sur le disque ($R=35\text{mm}$) par la touche TRACK FWD \blacktriangleright ou la touche REV \blacktriangleleft .
2. Appuyer sur la touche OUTPUT, puis sur la touche PLAY \triangleright , dans cet ordre, pour fermer le circuit servo de la mise au point, puis celui de la rotation.
3. Insérer un tournevis ordinaire dans le réseau de diffraction pour trouver le point zéro. Pour plus de détails, voir page suivante.
4. Si l'on tourne lentement le tournevis dans le sens des aiguilles d'une montre à partir du point zéro, l'amplitude de l'onde augmente graduellement et si l'on continue à tourner le tournevis, l'amplitude de l'onde diminue de nouveau. Tourner le tournevis dans le sens des aiguilles d'une montre à partir du point zéro et régler le réseau de diffraction au premier point où l'amplitude de l'onde atteint son maximum.

Référence: La Figure 3 illustre la relation entre l'angle du faisceau de l'alignement et la piste et la forme d'onde.

Remarque: L'amplitude du signal d'erreur d'alignement se situe aux environs de 3Vc-c (quand un filtre passe-bas de $39\text{k}\Omega + 0.001\mu\text{F}$ est utilisé). Si cette amplitude est extrêmement petite (2Vc-c ou moins), il peut s'ensuivre un mauvais fonctionnement de la lentille d'objectif ou du capteur. Si la différence entre l'amplitude du signal d'erreur au bord le plus intérieur et au bord le plus extérieur du disque est supérieure à 10%, ceci signifie que le réseau de diffraction n'est pas réglé à son point optimum. Dans ce cas, recommencer le réglage.

5. Remplacer le capteur plus ou moins à mi-chemin sur le disque par la touche TRACK REV \blacktriangleleft , appuyer sur la touche PAUSE \square et vérifier que le numéro de piste et la durée écoulée sont affichés sur le panneau avant. Si ces paramètres n'apparaissent pas ce moment, ou que la durée écoulée change de manière irrégulière, vérifier le point zéro et recommencer le réglage du réseau de diffraction.





Figure 2



[Repérage du point zéro]

Quand le tournevis est introduit dans la fente de réglage du réseau de diffraction et que l'angle du réseau de diffraction est modifié, l'amplitude du signal d'erreur d'alignement à TP1, broche 2, change. Dans les limites de la plage du réseau de diffraction, il existe six emplacements où l'amplitude de l'onde atteint le minimum. Mais l'enveloppe de la forme d'onde n'est régulière qu'à un seul de ces emplacements. Ce point se situe à l'endroit où les trois rayons laser, divisés par le réseau de diffraction, se situent exactement sur la même piste (voir Figure 3).

Ce point s'appelle le point zéro. Lors du réglage du réseau de diffraction, ce point zéro est repéré et utilisé comme position de référence.

Tourner le réseau de diffraction dans le sens des aiguilles d'une montre Tourner le réseau de diffraction dans le sens contraire des aiguilles d'une montre






Figure 3




3. Réglage d'équilibrage d'erreur d'alignement

| | | | |
|--|---|--------------------------|---|
| • Objectif | Pour corriger la variation de sensibilité de la photodiode d'alignement | | |
| • Symptôme quand déréglé | La lecture ne commence pas, la recherche de piste est impossible. | | |
| • Raccordement des instruments de mesure | Raccorder l'oscilloscope à TP1, broche 2 (TRK ERR). Cette connexion peut être faite par l'intermédiaire d'un filtre passe-bas. | • Etat du lecteur | Mode d'essai, circuits servo de la mise au point et de la rotation fermés, circuit servo de l'alignement ouvert |
| | [Réglages] 50 mV/division 5 ms/division mode CC | • Emplacement du réglage | VR102 (TRK BAL) |
| | | • Disque | YEDS-7 |

[Marche à suivre]

1. Déplacer le capteur à mi-chemin sur le disque ($R=35\text{mm}$) par la touche TRACK FWD \gg ou la touche REV \ll .
2. Appuyer sur la touche OUTPUT, puis sur la touche PLAY \triangleright , dans cet ordre, pour fermer le circuit servo de la mise au point, puis celui de la rotation.
3. Aligner la ligne lumineuse (masse) au centre de l'écran de l'oscilloscope et placer celui-ci en mode CC.
4. Ajuster VR102 (TRK BAL) de façon que l'amplitude positive et l'amplitude négative du signal d'erreur d'alignement à TP1, broche 2 (TRK ERR) soient identiques (c'est-à-dire, qu'il n'y ait aucun composant CC).



S'il y a un composant CC


S'il n'y a pas de composant CC

4. Réglage d'inclinaison radiale/tangentielle du capteur


| | | | |
|--|--|--------------------------|---|
| • Objectif | Pour régler l'angle du capteur par rapport au disque, de façon que les rayons laser frappent verticalement le disque et permettre ainsi la lecture optimum des signaux RF. | | |
| • Symptôme quand déréglé | Son interrompu; certains disques peuvent être lus et pas d'autres. | | |
| • Raccordement des instruments de mesure | Raccorder l'oscilloscope à TP1, broche 1 (RF). | • Etat du lecteur | Mode d'essai, lecture |
| | [Réglages] 20 mV/division 200 ns/division mode CA | • Emplacement du réglage | Vis de réglage d'inclinaison radiale Vis de réglage d'inclinaison tangentielle |
| | | • Disque | YEDS-7 |

[Marche à suivre]

1. Dans le cas d'un lecteur multidisque, utiliser la touche TRACK FWD ou la touche REV pour déplacer le capteur à mi-chemin sur le disque (R=35mm).
Appuyer sur la touche OUTPUT, PLAY et PAUSE dans cet ordre, afin de fermer le circuit servo de la mise au point, puis celui de la rotation et placer le lecteur en mode de lecture.
 2. D'abord, ajuster la vis d'inclinaison radiale à l'aide un tournevis Phillips, de façon que le motif en oeil (c'est-à-dire, le diamant au centre du signal RF) soit le plus clairement visible.
 3. Ensuite, ajuster la vis d'inclinaison tangentielle à l'aide un tournevis Phillips, de façon que le motif en oeil (c'est-à-dire, le diamant au centre du signal RF) soit le plus clairement visible (Figure 5).
 4. Ajuster de nouveau la vis d'inclinaison radiale et la vis d'inclinaison tangentielle de façon que le motif en oeil soit le plus clairement visible. Le cas échéant, régler les deux vis de façon que le motif en oeil soit le plus clairement visible.
- Remarque : "Radial" et "tangentielle" se rapportent aux sens par rapport au disque illustré à la Figure 4.



Disque
Figure 4



Emplacements des réglages




Figure 5 Motif en œil

5. Réglage du niveau RF (niveau RF)

| | | | |
|--|--|--------------------------|-----------------------------|
| • Objectif | Pour optimiser l'amplitude du signal RF de lecture | | |
| • Symptôme quand déréglé | Pas de lecture ni de recherche | | |
| • Raccordement des instruments de mesure | Raccorder l'oscilloscope à TP1, broche 1 (RF). | • Etat du lecteur | Mode d'essai, lecture |
| | [Réglages] 50 mV/division 10 ms/division mode CA | • Emplacement du réglage | VR1 (alimentation du laser) |
| | | • Disque | YEDS-7 |

[Marche à suivre]

1. Placer le capteur à mi-chemin sur le disque ($R=35\text{mm}$) à l'aide la touche TRACK FWD ou la touche REV. Ensuite, appuyer sur la touche OUTPUT puis sur la touche PLAY, dans cet ordre, pour fermer les circuits servo respectifs et mettre le lecteur en mode de lecteur.
2. Ajuster VR1 (alimentation du laser) de façon que l'amplitude du signal RF atteigne $1,2 V_{c-c} \pm 0,1 V$.

6. Réglage de gain de boucle asservie de la mise au point

| | | | |
|--|---|--------------------------------------|---------------------------|
| • Objectif | Pour optimiser le gain de la boucle d'asservissement de la mise au point. | | |
| • Symptôme quand déréglé | La lecture ne commence pas ou l'actuateur de la mise au point est parasité. | | |
| • Raccordement des instruments de mesure | Voir Figure 6. | • Etat du lecteur | Mode d'essai, lecture |
| | [Réglages] CAN.1 CAN.2 20 mV/division 5 mV/division Mode X-Y | • Emplacement du réglage • Disque | VR152 (FCS GAN) YEDS-7 |

[Marche à suivre]

1. Régler la sortie du générateur AF sur 1,2 kHz et 1 V_{c-c}.
2. Appuyer sur la touche TRACK FWD ou la touche REV pour placer la capteur à mi-chemin sur le disque (R=35mm). Ensuite, appuyer sur la touche OUTPUT, la touche PLAY, puis sur la touche PAUSE, dans cet ordre, pour fermer les circuits servo respectifs et placer le lecteur en mode de lecture.
3. Ajuster VR152 (FSC GAN) de façon que la forme d'onde de Lissajous soit symétrique aux alentours de l'axe X et l'axe Y.





Figure 6


Adjustment de gain de mise au point



Gain Supérieur



Gain optimum



Gain inférieur

7. Réglage de gain de boucle asservie de l'alignement

| | | | |
|--|--|--------------------------------------|---------------------------|
| • Objectif | Pour optimiser le gain de la boucle d'asservissement de l'alignement. | | |
| • Symptôme quand déréglé | La lecture ne commence pas, l'actuateur est parasité pendant la recherche, ou des pistes sont sautées. | | |
| • Raccordement des instruments de mesure | Voir Figure 7. | • Etat du lecteur | Mode d'essai, lecture |
| | [Réglages] CAN.1 CAN.2 50 mV/division 50mV/division Mode X-Y | • Emplacement du réglage • Disque | VR151 (TRK GAN) YEDS-7 |

[Marche à suivre]

1. Régler la sortie du générateur AF sur 1,2 kHz et 1 Vc-c.
2. Appuyer sur la touche TRACK FWD ou la touche REV pour placer la capteur à mi-chemin sur le disque (R=35mm). Ensuite, appuyer sur la touche OUTPUT, la touche PLAY, puis sur la touche PAUSE, dans cet ordre, pour fermer les circuits servo respectifs et placer le lecteur en mode de lecture.
3. Ajuster VR151 (TRK GAN) de façon que la forme d'onde de Lissajous soit symétrique aux alentours de l'axe X et l'axe Y.






Figure 7

Adjustment de gain d'alignement



Gain Supérieur



Gain optimum



Gain inférieur

8. Vérification du signal d'erreur de la mise au point

| | | | |
|--|---|--------------------------|---------------------|
| • Objectif | Pour juger si le capteur est bon ou pas, en observant le signal d'erreur de la mise au point. L'état du capteur s'évalue à partir de l'amplitude du signal d'erreur d'alignement (comme décrit dans le paragraphe relatif à l'équilibrage d'erreur d'alignement), ainsi qu'à partir de la forme d'onde du signal d'erreur de mise au point. | | |
| • Symptôme quand déréglé | | | |
| • Raccordement des instruments de mesure | Raccorder l'oscilloscope à TP1, broche 6 (FCS ERR). | • Etat du lecteur | Mode de test, arrêt |
| | [Réglages] 100 mV/division 5 ms/division mode CC | • Emplacement du réglage | Aucun |
| | | • Disque | YEDS-7 |

[Marche à suivre]

1. Raccorder TP1, broche 5 à la masse.
2. Installer le disque.
3. Tout en regardant l'écran de l'oscilloscope, appuyer sur la touche OUTPUT et observer la forme d'onde de la Figure 8, pendant quelques instants. Vérifier que l'amplitude atteint au moins $2,5 V_{c-c}$ et que les amplitudes positive et négative soient égales. Comme la forme ne sort que pour un moment, quand la touche OUTPUT est enclenchée, appuyer sur à plusieurs reprises sur cette touche, jusqu'à ce que la forme d'onde ait été vérifiée.




Figure 8

[Evaluation du capteur]

Ne pas tenter d'évaluer l'état du capteur tant que tous les réglages ne sont pas corrects. Les cas suivants témoignent de l'anomalie du capteur.

1. L'amplitude du signal d'erreur d'alignement est extrêmement petite (inférieure à $2 V_{c-c}$).
2. L'amplitude du signal d'erreur de mise au point est extrêmement petite (inférieure à $2,5 V_{c-c}$).
3. Les amplitudes positive et négative du signal d'erreur de mise au point sont extrêmement asymétriques (taux 2:1 ou plus).
4. Le signal RF est trop petit (inférieur à $0,8 V_{c-c}$) et même si VR1 (alimentation du laser) est ajustée, le signal RF ne peut être élevé au niveau standard.

6. AJUSTE

Si un reproductor de discos compactos se ajusta incorrecta o inadecuadamente, puede funcionar mal o no trabajar incluso aunque no exista ningún problema en el captor ni en los circuitos. Ajuste correctamente siguiendo el procedimiento de ajuste.

6-1. Ítemes de ajuste/verificación y orden

| Paso | Ítem | Punto de prueba | Lugar de ajuste |
|------|--|---|--|
| 1 | Ajuste del descentramiento de enfoque | TP1, Patilla 6 (FCS.ERR) | VR103 (FCS.OFS) |
| 2 | Ajuste de retícula | TP1, Patilla 2 (TRK.ERR) | Ranura de ajuste de retícula |
| 3 | Ajuste del equilibrio de ajuste de seguimient | TP1, Patilla 2 (TRK.ERR) | VR102 (TRK.BAL) |
| 4 | Ajuste de la inclinación en sentido radial/tangencial del captor | TP1, Patilla 1 (RF) | Tornillo de ajuste de la inclinación radial Tornillo de ajuste de la inclinación tangencial |
| 5 | Ajuste del nivel de RF | TP1, Patilla 1 (RF) | VR1 (Nivel de RF) |
| 6 | Ajuste de la ganancia del bucle del servo de enfoque | TP1, Patilla 5 (FCS.IN) TP1, Patilla 6 (FCS.ERR) | VR152 (FCS.GAN) |
| 7 | Ajuste de ganancia del bucle del servo de seguimiento | TP1, Patilla 3 (TRK.IN) TP1, Patilla 2 (TRK.ERR) | VR151 (TRK.GAN) |
| 8 | Verificación de la señal de error de enfoque | TP1, Patilla 6 (FCS.ERR) | — |

● Tabla de abreviaturas

FCS.ERR : Error de enfoque
 FCS.OFS : Descentramiento de enfoque
 TRK.ERR : Error de seguimiento
 TRK.BAL : Equilibrio de seguimient
 FCS.GAN : Ganacia de enfoque
 TRK.GAN : Ganacia de seguimiento
 FCS.IN : Entrada de enfoque
 TRK.IN : Entrada de seguimiento

6-2. Instrumentos y herramientas de medición

1. Osciloscopio de doble traza (Sonda de 10 : 1)
2. Oscilador de baja frecuencia
3. Disco de prueba (YEDS-7)
4. Filtro de paso bajo (39k Ω , 0,001 μ F)
5. Resistor (100k Ω)
6. Herramientas estándar

6-3. Ubicación de los puntos de prueba y los resistores variables de ajuste




Figura 1 Lugares de ajuste

6-4. Notas

1. Emplee una sonda de 10:1 para el osciloscopio.
2. Todas las posiciones de los mandos (ajustes) para el osciloscopio de los procedimientos de ajuste son para cuando se emplee la sonda de 10:1.

6-5. Modo de prueba

Estos modelos poseen un modo de prueba que permite realizar fácilmente los ajustes y las comprobaciones requeridos para el servicio. Cuando estos modelos estén en el modo de prueba, las teclas del panel frontal trabajarán de forma diferente a la normal. Los ajustes y las comprobaciones podrán realizarse accionando estas teclas de acuerdo con el procedimiento correcto. Para estos modelos, todos los ajustes se realizarán en el modo de prueba.

[Puesta de estos modelos en el modo de prueba]

A continuación se indica cómo poner estos modelos en el modo de prueba.

1. Ponga en OFF el interruptor de alimentación.
2. Cortocircuite los hilos de puenteado de modo de prueba. (Consulte la figura 1.)
3. Ponga en ON el interruptor de alimentación.

Cuando haya ajustado correctamente el modo de prueba, la visualización será diferente a la obtenida normalmente al conectar la alimentación. Si la visualización sigue siendo la normal, el modo de prueba no se habrá ajustado normalmente, por lo que tendrá que repetir los pasos 1 a 3.

[Desactivación del modo de prueba]

A continuación se indica el procedimiento para desactivar el modo de prueba.

1. Presione la tecla STOP y cese todas las operaciones.
2. Ponga en OFF el interruptor de alimentación del panel frontal.

| Código | Nombre de la tecla | Función en el modo de prueba | Explicación |
|--------|--------------------|--|--|
| | OUTPUT | Cierre del servo de enfoque | <p>El diodo láser se encenderá y el actuador de enfoque se eleva, después se descende lentamente, y el servo de enfoque se cerrará en el punto en el que el objetivo se enfoca sobre el disco.</p> <p>Con el reproductor en este estado, si gira ligeramente con la mano el disco parado, podrá oír el sonido del servo de enfoque.</p> <p>Si puede oír este sonido, el servo de enfoque estará funcionando correctamente. Si presiona esta tecla sin disco montado, el diodo láser se encenderá, el actuador de enfoque se ve empujado hacia arriba, y después se levantará y descenderá y se eleva dos veces, y volverá a su posición original.</p> |
| ▷ | PLAY | Activación del servo del eje | <p>Pondrá en marcha el motor del eje haciéndolo girar hacia la derecha y después la rotación del disco alcanzará la velocidad prescrita (unas 500 rpm en la periferia interior), y pondrá el servo del eje en un bucle cerrado.</p> <p>Tenga cuidado. Si presiona esta tecla cuando no haya disco montado, el motor del eje girará a la velocidad máxima.</p> <p>Si el servo de enfoque no pasa correctamente a un bucle cerrado, o si el haz láserico incide en la sección del espejo en el la periferia del disco, ocurrirá el mismo síntoma.</p> |
| ⏏ | PAUSE | Apertura/cierre del servo de seguimiento | <p>Si presiona esta tecla cuando el servo de enfoque y el servo del eje están funcionando correctamente en bucles cerrados, el servo de seguimiento se pondrá en bucle cerrado, en el panel frontal se visualizarán el número de canción que este reproduciéndose y el tiempo transcurrido, y se producirá la salida de la señal de reproducción.</p> <p>Si el tiempo transcurrido no se visualiza o no se cuenta correctamente, o si el sonido no se reproduce correctamente, es posible que el rayo láserico esté incidiendo en la sección sin sonido grabado en el borde exterior del disco, o que exista algún otro problema.</p> <p>Esta tecla es basculante (de acción alternativa) y abre/cierra el servo de seguimiento alternativamente. Esta tecla no funcionará cuando no haya disco montado.</p> |

| Código | Nombre de la tecla | Fonción en el mode de prueba | Explicación |
|--------|--------------------|---|--|
| ⏮ | TRACK REV | Retroceso del carro (hacia adentro) | Moverá la posición del captor hacia el diámetro interior del disco. Si presiona esta tecla con el servo de seguimiento en bucle cerrado, dicho bucle pasará automáticamente a bucle abierto. Como el captor no se para automáticamente en el puto final mecánico en el modo de prueba, tenga cuidado cuando realice esta operación. |
| ⏭ | TRACK FWD | Avance del carro (hacia afuera) | Moverá la posición del captor hacia la periferia del disco. Si presiona esta tecla con el servo de seguimiento en bucle cerrado, dicho bucle pasará automáticamente a bucle abierto. Como el captor no se para automáticamente en el puto final mecánico en el modo de prueba, tenga cuidado cuando realice esta operación. |
| □ | STOP | Parada | Inicializa y se para la rotacion del desco. El captor y el disco permanecen donde están cuando se presiona esta tecla. |
| △ | OPEN/CLOSE | Apertura/cierre de la bandeja del disco | Abrirá/cerrará la bandeja del disco. Esta tecla es baseulante de accion alternativa y abre/cierra la bandeja alternativamente. |

[Cómo reproducir un disco en el modo de prueba]

En el modo de prueba, como los servos funcionan independientemente, la reproducción de un disco requiere el que usted emplee las teclas en el orden correcto para cerrar los servos.

A continuación se indica la secuencia de operación de teclas para reproducir un disco en el modo de prueba.

OUTPUT ⏮⏭

Hará que se encienda el diodo láser y cerrará el servo de enfoque.



PLAY ▶

Pondrá en marcha el motor del eje y hará que se cierre el servo del eje.



PAUSE ⏏

Cerrará el servo de seguimiento.

Espere de 2 a 3 segundos por lo menos entre cada una de estas operaciones.

1. Ajuste del descentramiento del enfoque

| | | | |
|---|---|--|--|
| <ul style="list-style-type: none"> • Objetivo • Síntomas en caso de desajuste | <p>Ajuste de la tensión de CC para el amplificador de error de enfoque.</p> <p>El reproductor no enfoca y la señal de RF contiene perturbaciones.</p> | | |
| <ul style="list-style-type: none"> • Conexión de los instrumentos de medición | <p>Conecte el osciloscopio a TP1, patilla 6, (FCS ERR).</p> <p>[Ajustes] 5 mV/división 10 ms/división modo de CC</p> | <ul style="list-style-type: none"> • Estado del reproductor • Lugar de ajuste • Disco | <p>Modo de prueba, parado (con el interruptor de alimentación en ON)</p> <p>VR103 (FCS OFS)</p> <p>No es necesario</p> |

[Procedimiento]

Ajuste VR103 (FCS OFS) de forma que la tensión de CC de TP1, patilla 6, (FCS ERR) sea de -150 ± 50 mV.

2. Ajuste de retícula

| | | | |
|--|--|------------------------------|--|
| • Objetivo | Alineación de los puntos del haz láserico de generación de error de seguimiento al ángulo óptimo en la pista | | |
| • Síntomas en caso de desajuste | La reproducción no se inicia, la búsqueda de canciones es imposible, las pistas se saltan. | | |
| • Conexión de los instrumentos de medición | Conecte el osciloscopio a TP1, patilla 2, (TRK ERR) a través de un filtro de paso bajo. (Consulte la figura 2) | • Estado del reproductor | Modo de prueba, servos de enfoque y del eje cerrados, y servo de seguimiento abierto |
| | [Ajustes] 50 mV/división 5 ms/división modo de CC | • Lugar de ajuste • Disco | Ranura de ajuste de retícula del captor YEDS-7 |

[Procedimiento]

1. Mueva el captor hasta la mitad del disco ($R=35\text{mm}$) con la tecla TRACK FWD \gg o REV \ll de forma que la ranura de ajuste de la retícula quede en el borde exterior del disco, donde puede ajustarse.
2. Presione la tecla OUTPUT, y después la tecla PLAY \triangleright , por este orden, a fin de cerrar el servo de enfoque y después el servo del eje.
3. Inserte un destornillador normal en la ranura de ajuste de la retícula y ajuste la retícula hasta encontrar el punto nulo. Para más detalles, consulte la página siguiente.
4. Si gira lentamente el destornillador hacia la derecha desde el punto nulo, la amplitud de la onda aumentará gradualmente. Después, si continúa girando el destornillador, la amplitud de la onda se volverá otra vez más pequeña. Gire el destornillador hacia la derecha desde el punto nulo y ajuste la retícula al primer punto en el que la amplitud de la onda alcance su valor máximo.

Referencia: En la figura 3 se muestra la relación entre el ángulo del haz de seguimiento con la pista y la forma de onda.

Nota: La amplitud de la señal de error de seguimiento será de aproximadamente $3V_p$ -p (cuando se emplee un filtro de paso bajo de $38k\Omega, 0.001\mu F$). Si esta amplitud es extremadamente pequeña ($2V_p$ -p o menos), la causa será el funcionamiento malo en el lente objetivo o en el captador. Si la diferencia entre la amplitud de la señal de error en el borde interior y exterior del disco es superior al 10%, la retícula no estará ajustada al punto óptimo, por lo que tendrá que volver a ajustarla.

5. Devuelva el captor hasta la mitad más o menos del disco con la tecla TRACK REV \ll , presione la tecla PAUSE \square , y vuelva a comprobar si en el panel frontal se visualizan el número de canción y el tiempo transcurrido. Si no se visualizan esta vez, o si el tiempo transcurrido cambia irregularmente, vuelva a comprobar el punto nulo y ajuste otra vez la retícula.





Figura 2



[Cómo encontrar el punto nulo]

Cuando inserte el destornillador normal en la ranura para el ajuste de la retícula y cambie el ángulo de la misma. La amplitud de la señal de error de seguimiento de TP1, patilla 2, cambiará. Dentro del margen para la retícula existen cinco o seis lugares en los que la amplitud alcanza el valor mínimo. De estos cinco o seis lugares, solamente hay uno en el que la envolvente de la forma de onda es uniforme. Este lugar es donde los tres haces lásericos divididos por la retícula se encuentran exactamente sobre la misma pista. (Consulte la figura 3.)

Este punto se denomina punto nulo. Cuando ajuste la retícula, este punto se encontrará y empleará como posición de referencia.





Figura 3






Figura 5 Patron optico

5. Ajuste del nivel de RF

| | | | |
|--|---|----------------------------------|---------------------------------------|
| • Objetivo | Optimización de la amplitud de la señal de RF de reproducción | | |
| • Síntomas en caso de desajuste | La reproducción no se inicia o la búsqueda de canciones es imposible. | | |
| • Conexión de los instrumentos de medición | Conecte el osciloscopio a TP1, patilla 1, (RF). | • Estado del reproductor | Modo de prueba, reproducción |
| | [Ajustes] 50 mV/división 10ms/división modo de CA | • Lugar de ajuste • Disco | VR1 (potencia de láser) YEDS-7 |

[Procedimiento]

1. Mueva el captor hasta la mitad del disco (R=35mm) con la tecla TRACK FWD ►► o REV ◄◄, presione la tecla OUTPUT, después la tecla PLAY ►, por este orden a fin de cerrar los servos respectivos, y ponga el reproductor en el modo de reproducción.
2. Ajuste VR1 (potencia de láser) de forma que la amplitud de la señal de RF sea de $1,2 V_{p-p} \pm 0,1 V$.

6. Ajuste de la ganancia del bucle del servo de enfoque

| | | | |
|--|--|------------------------------|------------------------------|
| • Objetivo | Optimización de la ganancia del bucle del servo de enfoque | | |
| • Síntomas en caso de desajuste | La reproducción no se inicia o el actuador de enfoque produce ruido. | | |
| • Conexión de los instrumentos de medición | Consulte la figura 6. | • Estado del reproductor | Modo de prueba, reproducción |
| | [Ajustes] CH1 CH2 20 mV/división 5 mV/división Modo X - Y | • Lugar de ajuste • Disco | VR152 (FCS GAN) YEDS-7 |

[Procedimiento]

1. Ajuste la salida del generador de AF a 1,2 kHz y 1 Vp-p.
2. Presione la tecla TRACK FWD \gg o REV \ll para mover el captor hasta la mitad del disco (R=35mm), y después presione la tecla OUTPUT, la tecla PLAY \triangleright , y después la tecla PAUSE \square , por este orden, a fin de cerrar los servos correspondientes y poner el reproductor en el modo de reproducción.
3. Ajuste VR152 (FCS GAN) hasta que la forma de onda de Lissajous sea simétrica alrededor del eje X y el eje Y.





Figura 6


Ajuste de la ganancia de enfoque



Ganancia superior



Ganancia óptima







Ganancia inferior

7. Ajuste de la ganancia del bucle del servo de seguimiento

| | | | |
|--|---|---|--------------------------------------|
| • Objetivo | Optimización de la ganancia del bucle del servo de seguimiento | | |
| • Síntomas en caso de desajuste | La reproducción no se inicia, el actuador de enfoque produce ruido, o se saltan pistas. | | |
| • Conexión de los instrumentos de medición | Consulte la figura 7. | • Estado del reproductor | Mode de prueba, reproducción |
| | <p>[Ajustes]</p> <p>CH1 CH2</p> <p>50 mV/división 50mV/división</p> <p>Modo X - Y</p> | <p>• Lugar de ajuste</p> <p>• Disco</p> | <p>VR151 (TRK GAN)</p> <p>YEDS-7</p> |

[Procedimiento]

1. Ajuste la salida del generador de AF a 1,2 kHz y 1 Vp-p.
2. Presione la tecla TRACK FWD  o REV  para mover el captor hasta la mitad del disco (R=35mm), y después presione la tecla OUTPUT, la tecla PLAY , y la tecla PAUSE , por este orden, a fin de cerrar los servos respectivos y poner el reproductor en el modo de reproducción.
3. Ajuste VR151 (TRK GAN) hasta que la forma de onda de Lissajous sea simétrica alrededor del eje X y el eje Y.





Figura 7

Ajuste de la ganancia de seguimiento



Ganancia superior



Ganancia óptima



Ganancia inferior

8. Verificación de la señal de error de enfoque (curva S de enfoque)

| | | | |
|--|---|--------------------------|------------------------|
| • Objetivo | Juzgar si el captor está bien o no observando la señal de error de enfoque. El captor se juzga por la amplitud de la señal de error de seguimiento (como se ha indicado en la sección sobre el ajuste del equilibrio de error de seguimiento) y la forma de onda de la señal de error de enfoque. | | |
| • Síntomas en caso de desajuste | | | |
| • Conexión de los instrumentos de medición | Conecte el osciloscopio a TP1, patilla 6, (FCS ERR). | • Estado del reproductor | Modo de prueba, parada |
| | [Ajustes] 100 mV/división 5 ms/división modo de CC | • Lugar de ajuste | Ninguno |
| | | • Disco | YEDS-7 |

[Procedimiento]

1. Conecte TP1, patilla 5, a masa.
2. Coloque el disco.
3. Contemplando la pantalla del osciloscopio, presione la tecla OUTPUT y observe durante un momento la forma de onda de la figura 8. Verifique si la amplitud es de 2,5Vp-p por lo menos y si la amplitud de las partes positiva y negativa son iguales. Como la forma de onda solamente sale durante un momento cuando se presiona la tecla OUTPUT, presione una y otra vez esta tecla hasta que logre comprobar la forma de onda.




Figura 8

[Juicio sobre el captor]

No juzgue el captor hasta haber finalizado correctamente todos los ajustes. En los casos siguientes es posible que haya algo erróneo en el captor.


1. La amplitud de la señal de error de seguimiento es extremadamente pequeña (menos de 2 Vp-p).
2. La amplitud de la señal de error de enfoque es extremadamente pequeña (menos de 2,5 Vp-p).
3. Las amplitudes de las partes positiva y negativa de la señal de error de enfoque son extremadamente asimétricas (relación de 2:1 o superior).
4. La señal de RF es demasiado pequeña (menos de 0,8 Vp-p) y aunque se ajuste VR1 (potencia de láser), la señal de RF no puede aumentarse hasta el nivel estándar.

7. IC INFORMATION

■ SM5840CP

Digital Filter

● Block Diagram



● Pin Assignment

(TOP VIEW)

| | | | |
|-------------------|---|----|------|
| $\overline{OW16}$ | 1 | 18 | DIN |
| XTI | 2 | 17 | BCKI |
| XTO | 3 | 16 | LRCI |
| CKO | 4 | 15 | BCKO |
| VSS | 5 | 14 | VDD |
| $\overline{OW20}$ | 6 | 13 | WCKO |
| DEEM | 7 | 12 | DOL |
| MUTE | 8 | 11 | DOR |
| \overline{RST} | 9 | 10 | DG |

● Pin Function

| No. | Pin name | I/O | Function |
|-----|-------------------|-----|---|
| 1 | $\overline{OW16}$ | I | Output bit rate select input 1. (*1) |
| 2 | XTI | I | Oscillator input. |
| 3 | XTO | O | Oscillator output. |
| 4 | CKO | O | Clock output. (Frequency is the same as XTI.) |
| 5 | V _{SS} | — | GND terminal. |
| 6 | $\overline{OW20}$ | I | Output bit rate select input 2. (*1) Refer to $\overline{OW16}$. |
| 7 | DEEM | I | De-emphasis signal input. L : De-emphasis OFF, H : De-emphasis ON |
| 8 | MUTE | I | Mute signal input. L : Soft mute OFF, H : Soft mute ON |
| 9 | \overline{RST} | I | System reset signal input. (Initialize) |
| 10 | DG | O | De-glitch output. |
| 11 | DOR | O | Data output for R ch. |
| 12 | DOL | O | Data output for L ch. |
| 13 | WCKO | O | Word clock output. |
| 14 | V _{DD} | — | Power supply input(+5V) |
| 15 | BCKO | O | Bit clock output. |
| 16 | LRCI | I | Sampling rate(fs) clock input for input data. |
| 17 | BCKI | I | Bit clock input |
| 18 | DIN | I | Data input |

*1 : Selection of output bit rate.

| Settings | | $\overline{OW20}$ | |
|-------------------|---|----------------------------------|--|
| | | H | L |
| $\overline{OW16}$ | H | 18bit output Noise shaper ON | 20bit output Noise shaper ON |
| | L | 16 bit output Noise shaper ON | 16bit output Noise shaper OFF (test mode) |

8. FOR PD-9700/KC, HEM, HB AND SD TYPES

8.1 CONTRAST OF MISCELLANEOUS PARTS

NOTES :

- Parts without part number cannot be supplied.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

The PD-9700/KC, HEM, HB and SD types are the same as the PD-41/KU type with the exception of the following sections.

| Mark | Symbol & Description | Part No. | | | | | Remarks |
|------|---|-------------------|---------------------|----------------------|---------------------|---------------------|-------------|
| | | PD-41 /KU type | PD-9700 /KC type | PD-9700 /HEM type | PD-9700 /HB type | PD-9700 /SD type | |
| | FL sheet | PAM1514 | PAM1514 | PAM1251 | PAM1251 | PAM1514 | For packing |
| | 33P F.F.C/30V | PDD1094 | PDD1094 | | | | |
| | 31P F.F.C/30V | | | PDD1092 | PDD1092 | PDD1092 | |
| | Cord with plug(mini plug) | PDE-319 | PDE-319 | | | | |
| | Front panel assembly | PEA1167 | PEA1166 | PEA1166 | PEA1166 | PEA1166 | |
| | CD packing case | PHG1677 | PHG1670 | PHG1670 | PHG1670 | PHG1670 | |
| | Recycle label | PRW1253 | PRW1253 | | | | |
| ⚠ | AC power cord | PDG1015 | PDG1015 | PDG1003 | PDG1036 | PDG1013 | |
| ⚠ | Strain relief | CM-22C | CM-22C | CM-22B | CM-22B | CM-22B | |
| ⚠ | Voltage selector | | | | | PSB1002 | |
| ⚠ | Power transformer(8VA) | PTT1166 | PTT1166 | PTT1167 | PTT1167 | PTT1168 | |
| ⚠ | Power transformer(15VA) | PTT1206 | PTT1206 | PTT1207 | PTT1207 | PTT1208 | |
| ⚠● | MAIN BOARD assembly | PWZ2150 | PWZ2150 | PWZ2151 | PWZ2153 | PWZ2151 | |
| ⚠ | PRIMARY BOARD assembly | Non supply | Non supply | Non supply | Non supply | Non supply | |
| ⚠● | ANALOG BOARD assembly | PWM1490 | PWM1490 | PWM1490 | PWM1492 | PWM1490 | |
| ● | FUNCTION A BOARD assembly | PWZ2168 | PWZ2168 | PWZ2169 | PWZ2169 | PWZ2169 | |
| | FUNCTION B BOARD assembly | Non supply | Non supply | Non supply | Non supply | Non supply | |
| | Operating instructions (German/Italian/Dutch/Swedish /Spanish/Portuguese) | | | PRF1048 | | | |

MAIN BOARD ASSEMBLY(PWZ2151 and PWZ2153)

The MAIN BOARD assemblies (PWZ2151 and PWZ2153) are the same as the MAIN BOARD assembly (PWZ2150) with the exception of the following sections.

| Mark | Symbol & Description | Part No. | | | Remarks |
|------|----------------------|-------------|---------|---------|---------|
| | | PWZ2150 | PWZ2151 | PWZ2153 | |
| | D391-D394 | 1SS254 | | | |
| | C391 | CGCYX103K25 | | | |
| | C392 | CCCSL101J50 | | | |
| | R391 | RD1/6PM244J | | | |
| | R392 | RD1/6PM102J | | | |
| | CN351 | HLEM33S | HLEM31S | HLEM31S | |
| | JA391,JA392 | RKN1004 | | | |

PRIMARY BOARD ASSEMBLY

The PRIMARY BOARD assemblies of PD-9700/KC, HEM, HB and SD are the same as the PRIMARY BOARD assembly of PD-41/KU for the service supply parts.

ANALOG BOARD ASSEMBLY(PWM1492)

The ANALOG BOARD assembly (PWM1492) is the same as the ANALOG BOARD assembly (PWM1490) with the exception of the following sections.

| Mark | Symbol & Description | Part No. | | Remarks |
|------|----------------------|----------|---------|---------|
| | | PWM1490 | PWM1492 | |
| | L540-L547 | PTH1010 | | |

FUNCTION A BOARD ASSEMBLY(PWZ2169)


The FUNCTION A BOARD assembly (PWZ2169) is the same as the FUNCTION A BOARD assembly (PWZ2168) with the exception of the following sections.

| Mark | Symbol & Description | Part No. | | Remarks |
|------|----------------------|----------|---------|---------|
| | | PWZ2168 | PWZ2169 | |
| | CN401 | HLEM33R | HLEM31R | |

FUNCTION B BOARD ASSEMBLY


The FUNCTION B BOARD assemblies of PD-9700/KC, HEM, HB and SD are the same as the FUNCTION B BOARD assembly of PD-41/KU for the service supply parts.

9. PANEL FACILITIES



FRONT PANEL

- ① **POWER** switch
- ② **DISPLAY** button and **OFF** indicator
- ③ **OUTPUT** button and **DIGITAL/ANALOG** indicators
- ④ **Remote sensor**
Receives the signal from the remote control unit.
- ⑤ **Disc tray**
- ⑥ **STOP** button (■)
- ⑦ **TRACK** search buttons (◀◀/▶▶)
- ⑧ **OPEN/CLOSE** button (▲)
- ⑨ **PLAY** button (▶) and indicator
- ⑩ **PAUSE** button (||) and indicator



REMOTE CONTROL UNIT

Remote control buttons with the same names or marks as buttons on the front panel of the player control the same operations as the corresponding front panel buttons.

- ① **OPEN/CLOSE button** (▲)
- ② **INDEX buttons** (← / →)
- ③ **MANUAL search buttons** (◀◀ / ▶▶)
- ④ **TRACK search buttons** (|◀◀ / ▶▶|)
- ⑤ **Track number/Digit buttons** (1-10, +10, ≥ 20)
- ⑥ **PGM (Program) button**
- ⑦ **CHECK button**
- ⑧ **REPEAT button**
- ⑨ **RANDOM PLAY button**
- ⑩ **PAUSE button** (||)
- ⑪ **STOP button** (■)
- ⑫ **PLAY button** (▶)
- ⑬ **TIME button**
- ⑭ **CLEAR button**

REMOTE CONTROL OPERATIONS

When operating the remote control unit, point the unit's infrared signal transmitter at the remote control receiver (REMOTE SENSOR) on the front panel of the player. The remote control unit can be used within a range of about 7 meters (23 feet) from the remote sensor, and within angles of up to about 30 degrees.

NOTE:

If the remote control sensor window is in a position where it receives strong light such as sunlight or fluorescent light, control may not be possible.

10. SPECIFICATIONS

1. General

| | |
|----------------------------------|--|
| Type | Compact disc digital audio system |
| Power requirements | |
| European model | AC 220 - 230 V, 50/60 Hz |
| U.K. and Australian models | AC 230 - 240 V, 60 Hz |
| U.S. and Canadian models | AC 120 V, 60Hz |
| Other models | AC 110/120 - 127/220/240 V (Switchable), 50/60 Hz |
| Power consumption | 22 W |
| Operating temperature | +5°C - +35°C +41°F - +95°F |
| Weight | 8.0 kg (17 lb, 10 oz) |
| External dimensions | 420(W) X 330(D) X 130(H) mm 16-9/16(W) X 13(D) X 5-2/16(H) in |

2. Audio section

| | |
|---------------------------|---|
| Frequency response | 2 Hz - 20 kHz |
| S/N ratio | 111 dB or more (EIAJ) |
| Dynamic range | 98 dB or more (EIAJ) |
| Channel separation | 107 dB or more (EIAJ) |
| Harmonic distortion | 0.002% or less (EIAJ) |
| Output voltage | 2.0V |
| Wow and flutter | Limit of measurement (±0.001% W.PEAK) or less (EIAJ) |
| Channels | 2-channel (stereo) |

3. Output terminal

| |
|--|
| Unbalanced type audio line output jacks |
| Optical and coaxial digital output jacks |
| Control input/output jacks (U.S. and Canadian models only) |
| CD-DECK SYNCHRO jack |

4. Functions

| |
|-------------------------|
| Basic operation buttons |
| ● PLAY, PAUSE, STOP |

| |
|-----------------|
| Search function |
| ● Direct play |
| ● Track search |
| ● Manual search |
| ● Index search |
| ● Time location |

Programming

- Maximum 24 steps
- Pause
- Program check/correction
- Program clear (single track or all tracks)

Repeat functions

- 1 track repeat
- All tracks repeat
- Program play repeat
- Random play repeat
- Program random play repeat

Random play (repeat also available)

Switching display

Time consumed, remaining time (track/disc), and total time

Timer start

5. Accessories

| | |
|--|---|
| ● Remote control unit | 1 |
| ● Size AAA/R03/dry batteries | 2 |
| ● Control cord (U.S. and Canadian models only) | 1 |
| ● Output cable | 1 |
| ● Operating instructions | 1 |

NOTE:

Specifications and design subject to possible modification without notice, due to improvements.